User Manual of Product 1:

Frigidaire EFMIS129-RED Mini Portable Compact Personal Fridge Cooler, 1 Gallons, 6 Cans

User Manual of Product 2:

RCA Mini Retro 6 Can Beverage Refrigerator-Black, RMIS129-BLACK, 0.15 cubic feet

Frigidaire

MINI BEVERAGE REFRIGERATOR



EFMIS129

Owner's Manual

Please Read These Instructions Carefully Before Use!

FRIGIDAIRE TM is a pending or registered trademark used under license from Electrolux Home Products,Inc

FEATURES

This thermoelectric unit is designed to be a portable storage container for cold drinks and cold food in "COLD" mode. The unit can chill to approximately 32°F/18°C below ambient temperature. The unit is powered by a 12 Volt DC system such as a vehicle, or can be powered from a house 110 Volt AC system.

MODE SELECTION

COLD - Move the sliding switch to "COLD", the unit will cool and a green light will be on.
OFF - Move the sliding switch to "OFF", the unit will be off.

MAINTENANCE

- Keep cords and cigarette lighter sockets clean at all times. Small tobacco or dirt particles in the socket or the plug may affect performance.
- The motor, fan and control panel vents should be cleaned periodically. While the unit is unplugged, clean the fan blades and motor shaft using a paint brush or other soft bristled brush. Remove all hair, dirt, or dust that may have accumulated.
- To clean, wipe the inside with a warm damp cloth or sponge. Do not use harsh or abrasive cleaners. A mild soap should be sufficient, but if stains or odours remain, household bleach or baking soda may be added to the washing solution. Keep the lid open for several hours after cleaning to allow the interior to thoroughly dry and to prevent odours from forming in the cooler.
- For long periods of storage, a small container of baking soda or charcoal, placed inside, will eliminate objectionable odours.

IMPORTANT NOTICE

1. The power switch should be put at the“OFF” position for over 5 minutes before changing the working mode.
2. When the cooling function is on,keep in a well-ventilated area. Don’t block the ventilation of the unit.
3. Do not operate under direct sunlight.
4. Do not disturb the airflow of the unit.
5. Do not pour water into the unit directly.
6. Do not use near water. Keep unit out of wet weather conditions.
7. Use damp cloth to clean the unit; do not submerge unit in water.
8. When leaving unit for a long time, put it in a well-ventilated area.
9. Avoid dropping unit.
10. Keep unit away from fire or other flammable substances.
11. Do not store meats, poultry, fish, dairy products and other items that may spoil in unit for more than one hour.
12. Use of extension cords is not recommended with this product.

FRIGIDAIRE TM is a pending or registered trademark used under license from Electrolux Home Products, Inc.

Safety instruction pertaining to risk of fire, electric shock, or injury to persons

WARNING-When using electric products, basic precautions should always be followed, including the following:

1) Read all the instructions before using the product.

2) Do not use this product near water-for example, near a bathtub, washbowl, kitchen sink, in a wet basement, or near a swimming pool, or the like.

3) This product should be used only with a cart or stand that is recommended by the manufacturer.

4) This product, either alone or in combination with an amplifier and headphones or speakers, may be capable of producing sound levels that could cause permanent hearing loss. Do not operate for a long period of time at a high volume level or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should consult an audiologist.

5) The product should be located so that its location or position does not interfere with its proper ventilation.

6) The product should be located away from heat sources such as radiators, heat registers, or other products that produce heat.

7) The product should be connected to a power supply only of the type described in the operating instructions or as marked on the product.

8) The power-supply cord of the product should be unplugged from the outlet when left unused for a long period of time.

9) Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.

10) The product should be serviced by qualified service personnel when:

a) The power-supply cord or the plug has been damaged or

b) Objects have fallen or liquid has been spilled onto the product or

c) The product has been exposed to rain or

d) The product does not appear to operate normally or exhibits a marked change in performance or

e) The product has been dropped or the enclosure damaged

11) Do not attempt to service the product beyond that described in the user-maintenance instructions. All other servicing should be referred to qualified service personnel.

Child entrapment warning:

DANGER or WARNING: Risk of child entrapment. Before you throw away your old mini beverage refrigerator. Take off the doors.

The appliance is not intended for use by young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.

LIMITED PRODUCT WARRANTY

This quality product is warranted to be free from manufacturer's defects in material and workmanship, provided that the unit is used under the normal operating conditions intended by the manufacturer.

Should you have any problem with this product, it is highly recommended to visit our website at www.curtisint.com before you take any other steps as we have additional copies of instruction manuals, operating manuals and trouble shooting tips on our website which gives you the answer on most of the questions you could have in operating the unit.

TERMS OF WARRANTY

C.I. Service Dept. warrants this product to be free from defects in materials and workmanship for 1 year on parts and 1 year on labor. If you originally purchased your product more than 1 year ago, a repair fee will apply.

Nothing within this warranty shall imply that C.I. will be responsible or liable for any damage to any items placed in this appliance, whether due to any defect of the appliance, or its use, whether proper or improper.

EXCLUSIONS

Save as herein provided, C.I. Service Dept. (Canada) or C.I. Service Dept. (USA), there are no other warranties, conditions, representations or guarantees, express or implied, made or intended by C.I. or its authorized distributors and all other warranties, conditions, representations or guarantees, including any warranties, conditions, representations or guarantees under any Sale of Goods Act or like legislation or statue is hereby expressly excluded. Save as herein provided, C.I. Service Dept. (Canada) or C.I. Service Dept. (USA), shall not be responsible for any damages to persons or property, including the unit itself, howsoever caused or any consequential damages arising from the malfunction of the unit and by the purchase of the unit, the purchaser does hereby agree to indemnify and save harmless C.I. from any claim for damages to persons or property caused by the unit.

TO OBTAIN REPAIRS UNDER THE TERMS OF THIS WARRANTY

1. The original purchaser must present a copy of the original bill of sale and the service warranty card.
2. Any alterations, abuse, misuse, battery corrosion or accidental damage voids the warranty.
3. The warranty does not cover cabinets and accessories.
4. No warranty or insurance contained or set out shall apply when damage or repair is caused by power failure; damage in transit or when moving the unit; improper power supply; use for commercial or industrial purposes; service calls resulting in customer education, etc.
5. The defective product should be taken or mailed to:

Canada
C.I. Service Dept.
315 Attwell Drive
Toronto, ON
M9W 5C1

U.S.A
Curtis International Ltd
c/o Lotus International Company
6880 Commerce Blvd.
Canton MI 48187
U.S.A.

For service assistance and product information, please call: 1-800-968-9853.

If mailing the product, the freight must be prepaid and a money order for $7.00 should be included to cover the cost of insurance and the return of the product.

6. C.I. reserves the right to repair or replace the parts, which have become defective.

To begin the **warranty repair process**, please note that you **MUST** obtain a **return authorization number prior** to returning your product for warranty based support. This can be placed under the 1-800-968-9853 contact line.

Model No. _____ Date Purchased _____ Serial No. _____

©Curtis International Ltd.
315 Attwell Drive, Toronto, Ontario M9W 5C1 www.curtisint.com



LIMITED PRODUCT WARRANTY
APPLIANCES

This appliance product is warranted to be free from manufacturer's defects in material and workmanship, provided that the unit is used under the normal operating conditions intended by the manufacturer.

Should you have any problem with this product, please and it is highly recommended to visit our website at www.curtis-young.com for FAQ's, Product Registration, Parts Diagrams, additional copies of instruction manuals, operating manuals, and trouble shooting tips so we can assist you and give you the answer or more of the questions you could have in operating the unit.

TERMS OF WARRANTY

C.I. Service Dept. warrants this product to be free from defects in materials and workmanship for 1 year on parts and 1 year on labor. If you originally purchased your product more than 1 year ago, a repair fee will apply.

Nothing within this warranty shall imply that C.I. will be responsible or liable for any damage to any items placed in this appliance, whether due to any defect of the appliance, or its use, whether proper or improper.

EXCLUDING

Save as herein provided, C.I. Service Dept. (Canada) or C.I. Service Dept. (USA), there are no other warranties, conditions, representations or guarantees, express or implied, made, or intended by C.I. or its authorized distributors, and all other warranties, conditions, representations or guarantees, including any warranties, conditions, representations or guarantees under any Sale of Goods Act or the legislation or regulations of any jurisdiction or any amendments thereto, are hereby excluded. C.I. Service Dept. (USA) Dept. (USA) shall not be responsible for any damages to persons or property, including fire, and buyer howsoever caused or any consequential damages arising from the malfunction of the unit and by the purchase of this unit the purchaser does hereby agree to indemnify and save harmless C.I. from any claim for damages by persons or property howsoever caused.

TO OBTAIN REPAIRS UNDER THE TERMS OF THIS WARRANTY

1. The original purchaser must present a copy of the original bill of sale and the service warranty card.
2. Any alterations, abuse, misuse, battery corrosion or accidental damage voids this warranty.
3. The warranty does not cover cabinet and accessories.
4. No warranty or insurance is offered or set out shall apply when damage or repair is caused by power surges, lightning, improper voltage supplied by the unit, improper power supply, use for commercial or industrial purposes, service calls resulting from improper installation, etc.
5. The defective product should be taken or mailed to:

Canada	U.S.A.
C.I. Service Dept.	Curtis International Ltd
7025 Beckett Drive, Unit 12	c/o Lodes International Company
Mississauga, ON	6900 Dumbarton Circle
L5S 2A3	Fremont, CA 94
	U.S.A.

For service assistance and product information, please call: 1-800-268-8853

If mailing the product, the freight must be prepaid and a money order for $7.50 should be included to cover the cost of insurance and the return of the product.

6. C.I. reserves the right to repair or replace the parts, which have become defective.

To begin the **warranty repair process**, please note that you **MUST** obtain a **return authorization number** prior to returning your product for warranty-based support. This can be placed under the 1-800-268-8853 contact line.

Dealer No. _____

Date Purchased _____ Serial No. _____

TRUX, TERTIA CHATTAT ARE TRADEMARKS OF HCA TRADEMARK MANAGEMENT USED UNDER LICENCE TO CURTIS INTERNATIONAL LTD.

RCA

MINI BEVERAGE REFRIGERATOR



RMIS129
Owner's Manual

Please Read These Instructions Carefully Before Use!

285X210mm 正

FEATURES

This thermoelectric unit is designed to be a portable storage container for cold drinks and cold food in "COLD" mode. The unit can also be approximately 30°F/16°C below ambient temperature. The unit is powered by a 12 Volt DC system such as a vehicle, or can be powered from a regular 110 Volt AC outlet.

MODE SELECTION

COLD - Move the rocker switch to "COLD", the unit will cool and a green light will be on.
OFF - Move the sliding switch to "OFF", the unit will be off.

MAINTENANCE

- Keep cords and cigarette lighter sockets clean at all times. Small balance or dirt particles in the socket or the plug may affect performance.
- The cords, fan and control panel exists should be cleaned periodically. While the unit is unplugged, clean the fan blades and motor shaft using a paint brush or other soft bristled brush. Remove all hair, dirt, or dust that may have accumulated.
- To clean, wipe the inside with a warm damp cloth or sponge. Do not use harsh or abrasive cleaners. A mild soap should be sufficient, but if stains or odours remain, household bleach or baking soda may be added to the washing solution. Keep the lid open for several hours after cleaning to allow the interior to thoroughly dry and to prevent odours from forming in the cooler.
- For long periods of storage, a small container of baking soda or charcoal placed inside, will eliminate objectionable odours.

IMPORTANT NOTICE

1. The power button should be put at the"OFF" position for over 5 minutes before changing the working mode.
2. When the cooling function is in use,keep in a well-ventilated area. Don't block the ventilation of the unit.
3. Do not operate under direct sunlight.
4. Do not obstruct the airflow of the unit.
5. Do not pour water into the unit directly.
6. Do not use near water. Keep unit out of wet weather conditions.
7. Use damp cloth to clean the unit; do not submerge unit in water.
8. When leaving unit for a long time, put it in a well-ventilated area.
9. Avoid dropping unit.
10. Keep unit away from fire or other flammable substances.
11. Do not store meats, poultry, fish, dairy products and other items that may spoil in unit for more than one hour.
12. Use of extension cords is not recommended with this product.

RCA AND THE RCA LOGO ARE TRADEMARKS OF RCA
PRODUCTS COMPANIES AND/OR AFFILIATES

Safety instructions pertaining to risk of fire, electric shock, or injury to persons
WARNING When using electric products, basic precautions should always be followed, including the following:
1) Read all the instructions before using the product.
2) Do not use this product near water for example, near a bathtub, washbowl, kitchen sink, or a wet basement, or near a swimming pool, or the like.
3) This product should be used only with a cart or stand that is recommended by the manufacturer.
4) This product, either alone or in combination with an amplifier and headphones or speakers, may be capable of producing sound levels that could cause permanent hearing loss. Do not operate for a long period of time at a high volume level or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should consult an audiologist.
5) The product should be located so that its location or position does not interfere with its proper ventilation.
6) The product should be located away from heat sources such as radiators, heat registers, or other products that produce heat.
7) The product should be connected to a power supply only of the type described in the operating instructions or as marked on the product.
8) The power-supply cord of the product should be unplugged from the outlet when left unused for a long period of time.
9) Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
10) The product should be serviced by qualified service personnel when:
a) The power-supply cord or the plug has been damaged; or
b) Objects have fallen, or liquid has been spilled onto the product; or
c) The product has been exposed to rain; or
d) The product does not appear to operate normally or exhibits a marked change in performance; or
e) The product has been dropped, or the enclosure damaged.
11) Do not attempt to service the product beyond that described in the user-maintenance instructions. All other servicing should be referred to qualified service personnel.

Child entrapment warning:
DANGER or WARNING: Risk of child entrapment. Before you throw away your old mini beverage refrigerator,
Take off the doors.
The appliance is not intended for use by young children or infirm persons without supervision.
Young children should be supervised to ensure that they do not play with the appliance.

285X210mm 反