

Refrigerator

User manual

RS25J50*

Free Standing Appliance

SAMSUNG

DA68-02981N-00.indb 1 2015. 3. 3. 9:34

Contents

Safety information **3**

Important safety symbols and precautions 4
Critical installation warnings 5
Installation cautions 8
Critical usage warnings 9
Usage cautions 13
Cleaning cautions 16
Critical disposal warnings 17
Additional tips for proper usage 18

Setting up **19**

Getting ready to install the refrigerator 19
Setting up the refrigerator 22
Removing the refrigerator doors 24
Leveling the refrigerator 29
Making minor adjustments between doors 30
Installing the water dispenser line 31
Completing the set up 35

Operating **36**

Checking the control panel 36
Using the control panel 38
Using the ice and cold water dispenser 41
Storing food 43
Removing the freezer/fridge accessories 45
Cleaning the refrigerator 46
Changing the water filter 48

Troubleshooting **54**

DA68-02981N-00.indb 2 2015. 3. 3. 9:34

Safety information

- Before using your new Samsung Side-By-Side Refrigerator, please read this manual thoroughly to ensure that you know how to operate the features and functions that your new appliance offers safely and efficiently.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or those who lack experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Because the following instructions cover various models, the characteristics of your refrigerator may differ slightly from the refrigerator described in this manual.
- If you have any question, contact us at 1-800-SAMSUNG or find help and information online at www.samsung.com.

DA68-02981N-00.indb 3 2015. 3. 3. 9:34

Safety information

Important safety symbols and precautions

⚠ **WARNING**

Hazards or unsafe practices that may result in **severe personal injury or death**.

⚠ **CAUTION**

Hazards or unsafe practices that may result in **minor personal injury or property damage**.

NOTE

- Do NOT attempt.
- Do NOT disassemble.
- Do NOT touch.
- Follow directions carefully.
- Unplug the power plug from the wall socket.
- Make sure the machine is grounded to prevent electric shock.
- Call the contact center for help.

These warning signs are here to prevent injury to you and others.
Please follow them carefully.
After reading this section, keep it in a safe place for future reference.

DA68-02981N-00.indb 4 2015. 3. 3. 9:34

Critical installation warnings

⚠ **WARNING**

⊘ • Do not install the refrigerator in a damp location or place where it may come in contact with water.

- Deteriorated insulation on electrical parts may cause an electric shock or fire.

• Do not place this refrigerator in direct sunlight or expose it to the heat from stoves, room heaters, or other appliances.

• Do not plug several appliances into the same multiple power strip. The refrigerator should always be plugged into its own individual electrical outlet which has a voltage rating that matches the voltage listed on the refrigerator's rating plate.

- This provides the best performance and also prevents overloading of house wiring circuits, which could cause a fire hazard from overheated wires.

• If the wall socket is loose, do not insert the power plug.

- There is a risk of electric shock of fire.

• Do not use a power cord that has cracks or abrasion damage along its length or at either end.

• Do not bend the power cord excessively or place heavy objects on it.

• Do not twist or tie the power cord.

• Do not hook the power cord over a metal object, place a heavy object on the power cord, insert the power cord between objects, or push the power cord into the space behind the appliance.

• When moving the refrigerator, be careful not to roll over or damage the power cord.

- This may result in an electric shock or fire.

• Never unplug your refrigerator by pulling on the power cord. Always grip the plug firmly and pull straight out from the outlet.

- Damage to the cord may cause a short-circuit, fire, and/or electric shock.

• Do not use aerosols near the refrigerator.

- Using aerosols near the refrigerator may cause an explosion or fire.

DA68-02981N-00.indb 5 2015. 3. 3. 9:34

Safety information

- Do not install this appliance near a heater or inflammable material.
- Do not install this appliance in a humid, oily, or dusty location , or in a location exposed to direct sunlight or water (rain, etc.).
- Do not install this appliance in a location where gas may leak.

- This may result in an electric shock or fire.

- This refrigerator must be properly located and installed in accordance with the instructions in this manual before you use it.
- Connect the power plug in the proper position with the cord hanging down.

- If you connect the power plug upside down, the wire can get cut off and cause a fire or electric shock.

- When moving the refrigerator, be careful not to roll over or damage the power cord.

- This constitutes a fire hazard.

- Make sure that the power plug is not crushed or damaged by the back of the refrigerator.
- Keep the packing materials out of reach of children.

- There is a risk of death from suffocation if a child puts the packing materials on his or her head.

- The appliance must be positioned so that the plug is accessible after installation.

- Failing to do so may result in an electric shock or fire due to electric leakage.

- You need to remove all the protective plastic film before you initially plug the product in.

DA68-02981N-00.indb 6 2015. 3. 3. 9:34

• The refrigerator must be safely grounded.
- Always make sure that you have grounded the refrigerator before attempting to investigate or repair any part of the appliance.
  Power leakages can cause severe electric shock.
• Never use gas pipes, telephone lines, or other potential lightning attractors as an electrical ground.
- Improper use of the grounding plug can result in a risk of electric shock.
  If it is necessary to use an extension cord, use only a 3-wire extension cord that has a 3-blade grounding plug and a 3-slot receptacle that will accept the plug on the appliance.
  The marked rating of the extension cord should be AC 115-120 V, 10 A, or more.
  If a grounding adapter is used, make sure the receptacle box is fully grounded.
• Plug the power plug into the wall socket firmly. Do not use a damaged power plug, damaged power cord, or loose wall socket.
- This may result in an electric shock or fire.

• If the power cord is damaged, have it replaced immediately by the manufacturer or one of its service agents.

DA68-02981N-00.indb 7 2015. 3. 3. 9:34

Safety information

Installation cautions

⚠ **CAUTION**

- Allow sufficient space around the refrigerator and install it on a flat surface.
- If your refrigerator is not level, the internal cooling system may not work correctly.
- Keep the ventilation space in the appliance enclosure or mounting structure clear of obstructions.

• Allow the appliance to stand for 2 hours after installation.

• We strongly recommend you have a qualified technician or service company install the refrigerator.

- Failing to do so may result in an electric shock, fire, explosion, problems with the product, or injury.

DA68-02981N-00.indb 8 2015. 3. 3. 9:34

Critical usage warnings

⚠ **WARNING**

⃠ • Do not insert the power plug into a wall socket with wet hands.
• Do not store articles on the top of the appliance.
- When you open or close the door, the articles may fall and cause personal injury and/or material damage.
• Do not insert hands, feet or metal objects (such as knives, etc.) into the bottom or the back of the refrigerator.
- This may result in an electric shock or injury.
- Any sharp edges may cause a personal injury
• Do not put a container filled with water on the refrigerator.
- If spilled, there is a risk of fire or electric shock.
• Children should be supervised to ensure that they do not play with the appliance.
- Keep fingers out of "pinch point" areas. Clearances between the doors and cabinet are necessarily small. Be careful when you open the doors if children are in the area.
• Do not let children hang on the door.
A serious injury may occur.
• Do not let children go inside the refrigerator.They could become trapped.
• Do not insert your hands into the bottom area under the appliance.
- Any sharp edges may cause personal injury.
• Do not let children step on a drawer cover.
- The drawer may break and cause them to slip.
• Do not overfill the refrigerator with food.
- When you open the door, an item may fall out and cause personal injury or material damage.
• Do not touch the inside walls of the freezer or products stored in the freezer with wet hands.
- This may cause frostbite.
• Never put fingers or other objects into the water dispenser hole, ice chute, or ice maker bucket.

DA68-02981N-00.indb 9 2015. 3. 3. 9:34

Safety information

- It may cause personal injury or material damage.
• Do not use or place any substances sensitive to temperature such as inflammable sprays, inflammable objects, dry ice, medicine, or chemicals near or inside of the refrigerator.
• Do not keep volatile or inflammable objects or substances (benzene, thinner, propane gas, alcohol, ether, LP gas, and other such products) in the refrigerator.
- This refrigerator is for storing food only.
- This may result in fire or explosion.
• Do not store pharmaceutical products, scientific materials, or temperature sensitive products in the refrigerator.
- Products that require strict temperature controls must not be stored in the refrigerator.
• Do not place or use an electrical appliance inside the refrigerator, unless it is of a type recommended by the manufacturer.
• Do not stand on top of the appliance or place objects (such as laundry, lighted candles, lighted cigarettes, dishes, chemicals, metal objects, etc.) on the appliance.
This may result in an electric shock, fire, problems with the product, or injury.
Do not put a container filled with water on the appliance.
- If spilled, there is a risk of fire or electric shock.
• Do not use mechanical devices or any other means to accelerate the defrosting process, other than those recommended by the manufacturer.
• Do not damage the refrigerant circuit.
• Do not spray volatile material such as insecticide onto the surface of the appliance.
- As well as being harmful to humans, it may also result in an electric shock, fire, or problems with the product.
• Never stare directly at the UV LED lamp for long periods of time.
- This may result in eye strain due to the ultraviolet rays.

DA68-02981N-00.indb 10 2015. 3. 3. 9:34

- Do not attempt to repair, disassemble, or modify the appliance yourself.
- Do not use any fuse (such as cooper, steel wire, etc.) other than a standard fuse.
- If your appliance needs to be repaired or reinstalled, contact your nearest service center.
- Failing to do so may result in an electric shock, fire, problems with the product, or injury.
- If the interior or exterior LED lamp has gone out, please contact your nearest service center.

- Children should be supervised to ensure that they do not play with the appliance.
- Keep fingers out of "pinch point" areas. : Clearances between the doors and cabinet are necessarily small.
  Be careful when you open the doors if children are in the area.
- Do not let children hang on the door.
  A serious injury may occur.
- Do not let children go inside the refrigerator. They could become trapped.
- Bottles should be stored tightly together so that they do not fall out.
- This product is intended only for the storage of food in a domestic environment.
- If a gas leak is detected, avoid any naked flames or potential sources of ignition, and air the room in which the appliance is standing for several minutes.
- Do not touch the appliance or power cord.
- Do not use a ventilating fan.
- A spark may result in explosion or fire.
- Use only the LED Lamps provided by the manufacturer or its service agents.

DA68-02981N-00.indb 11 2015. 3. 3. 9:34

Safety information

- If the refrigerator emits a burning smell or smoke, unplug the refrigerator immediately and contact your Samsung Electronics service center.
- If you experience difficulty changing a non-LED light, contact a Samsung service center.
- If the product is equipped with LED Lamps, do not disassemble the Lamp Covers and LED Lamps yourself.
- Please contact your service agents.
- If dust or water enters the refrigerator, unplug the refrigerator and contact your Samsung Electronics service center.
- There is a risk of fire.

DA68-02981N-00.indb 12 2015. 3. 3. 9:34

Usage cautions

⚠ CAUTION

⊘ • Do not re-freeze frozen foods that have thawed completely.
Do not place carbonated or fizzy drinks in the freezer compartment.
Do not put bottles or glass containers in the freezer.

- When the contents freeze, the glass may break and cause personal injury.

• Use only the ice maker provided with the refrigerator.

• Have the refrigerator's water supply installed by a suitably qualified person and connected only to a potable water supply.
To operate the ice maker properly, water pressure of 20 ~ 125 psi (138 ~ 862 kPa) is required.
If you will be away from home for a long period of time (on vacation, for example) and won't be using the water or ice dispensers, close the water valve.

- Otherwise, water leakage may occur.

• If you won't be using the refrigerator for a very long period of time, (3 weeks or more) empty the refrigerator, unplug it, close the water valve, wipe excess moisture from the inside walls, and leave the doors open to prevent odors and mold.

DA68-02981N-00.indb 13 2015. 3. 3. 9:34

Safety information

• Service Warranty and Modification.

- Any changes or modifications performed by a 3rd party on this finished appliance are not covered under Samsung warranty service, nor is Samsung responsible for safety issues that result from 3rd party modifications.
- Do not block the air vents inside the refrigerator.
- If the air vents are blocked, especially with a plastic bag, the refrigerator can be over cooled. If this cooling period lasts too long, the water filter may break and cause water leakage.
- If the refrigerator is disconnected from the power supply, you should wait for at least five minutes before plugging it back in.
- If you have a long vacation planned or do not intend to use the refrigerator for a long period of time, (3 weeks or more) empty the refrigerator, pull out the power plug, close the water valve, wipe excess moisture from the inside walls, and leave the doors open to prevent odors and mold.
- Letting the refrigerator run long periods of time without using it can cause the insulation to deteriorate and may cause a fire.
- To get the best performance from the product:
- Do not place food too close to the vents at the rear of the appliance as it can obstruct free air circulation in the refrigerator compartment.
- Wrap food up properly or place it in airtight containers before putting it into the refrigerator.
- Do not place glass bottles or carbonated beverages into the freezer. They can freeze and break.
  Broken beverage containers can cause injury.
- Please observe maximum storage times and expiration dates of frozen goods.
- There is no need to disconnect the refrigerator from the power supply if you will be away for less than three weeks.
  However, if you will be away for more than three weeks, remove all the food, unplug the refrigerator, close the water valve, wipe excess moisture from the inside walls, and leave the doors open to prevent odors and mold.

DA68-02981N-00.indb 14 2015. 3. 3. 9:34

• Fill the water tank and ice cube trays with potable water only (tap water, mineral water, or purified water).
- Do not fill the tank with tea or a Sports drink. This may damage the refrigerator.
• Do not strike or apply excessive force to any glass surface.
- Broken glass may result in a personal injury and/or property damage.

• If the product is flooded, make sure to contact your nearest service center.
- There is a risk of electric shock or fire.

DA68-02981N-00.indb 15 2015. 3. 3. 9:34

Safety information

Cleaning cautions

⚠ CAUTION

- Do not spray water directly on the inside or outside the refrigerator.
- There is a risk of fire or electric shock.
- Do not use a hair dryer to dry the inside of the refrigerator.
- Do not place a lighted candle in the refrigerator to remove bad odors.
- This may result in an electric shock or fire.

- Use a clean, dry cloth to remove any foreign matter or dust from the power plug blades.
  Do not use a wet or damp cloth when cleaning the plug.
- Otherwise, there is a risk of fire or electric shock.

- Before cleaning or performing maintenance, unplug the appliance from the wall socket.
- Failing to do so may result in an electric shock or fire.

⚠ WARNING

- This product contains chemicals known to the State of California to cause cancer and reproductive toxicity.

DA68-02981N-00.indb 16 2015. 3. 3. 9:34

Critical disposal warnings

⚠ **WARNING**

- DANGER : Risk of child entrapment.
  Before you throw away your old refrigerator or freezer:
- Take off the doors and door latch.
- Leave the shelves in place so that children cannot easily climb inside.
- Children trapped inside a refrigerator can hurt themselves or suffocate to death.

- Please dispose of the packaging material from this product in an environmentally friendly manner.
- Ensure that none of the pipes on the back of the appliance are damaged prior to disposal.
- R-600a or R-134a is used as a refrigerant. Check the compressor label on the rear of the appliance or the rating label inside the fridge to see which refrigerant is used for your refrigerator.
  If this product contains flammable gas (Refrigerant R-600a), contact your local authority in regard to safe disposal of this product.
- When disposing of this refrigerator, remove the door/door seals and door latch so that small children or animals cannot become trapped inside.
  Children should be supervised to ensure that they do not play with the appliance.
  If trapped inside, the child may get hurt or suffocate to death.
- Cyclopentane is used in the insulation.
  The gases in the insulation material require a special disposal procedure.
  Please contact your local authorities in regard to the environmentally safe disposal of this product.
- Keep all packaging materials well out of the reach of children, as packaging materials can be dangerous to children.
- If a child places a bag over his or her head, the child could suffocate.

DA68-02981N-00.indb 17 2015. 3. 3. 9:34

Safety information

Additional tips for proper usage

NOTE

- In the event of a power failure, call the local office of your Electricity Company and ask how long it is going to last.
- Most power failures that are corrected in an hour or two will not affect your refrigerator temperatures. However, you should minimize the number of door openings while the power is off.
- Should the power failure last more than 24 hours, remove and discard all frozen food.
- If a key is provided with refrigerator, the keys should be kept out of the reach of children and not be kept in the vicinity of the appliance.
- The appliance might not operate consistently (frozen contents can thaw or temperatures can become too warm in the frozen food compartment) when sited for an extended period of time in a location where ambient air temperatures are constantly below the temperatures for which the appliance is designed.
- Do not store food which goes bad easily at low temperature, such as bananas and melons.
- Your appliance is frost free, which means there is no need to manually defrost your appliance. This will be carried out automatically.
- Temperature rise during defrosting complies with ISO requirements. But If you want to prevent an undue rise in the temperature of frozen food while the appliance defrosts, wrap the frozen food in several layers of newspaper.
- Any increase in the temperature of frozen food during defrosting can shorten its storage life.
- Do not re-freeze frozen foods that have thawed completely.

DA68-02981N-00.indb 18 2015. 3. 3. 9:34

Setting up

Getting ready to install the refrigerator

Congratulations on your purchase of this Samsung French Door Refrigerator.
We hope you enjoy the state-of-art features and efficiencies that this new appliance offers.

Selecting the best location for the refrigerator

Choose :

- A location with easy access to a water supply.
- A location without direct exposure to sunlight.
- A location with level (or nearly level) flooring.
- A location with enough space for the refrigerator doors to open easily.
- A location that allows suffi cient space to the right, left, back, and top for air circulation. If the refrigerator does not have enough space, it can cause the bad infl uence to refrigeration effi ciency and power consumption.
- A location that allows you to move the refrigerator easily if it needs maintenance or service.
- Do not install the refrigerator in locations where the temperature is over 110 °F (43 °C) or below 50 °F (10 °C).

If your refrigerator is not level, the internal cooling system may not work correctly.
Refer to drawing and dimensions below for overall space required for use.



Depth "A"	36 1/5" (919 mm)
Width "B"	35 3/4" (908 mm)
Height "C"	68 3/5" (1742.5 mm)
Overall Height "D"	69 9/10" (1776 mm)

DA68-02981N-00.indb 19 2015. 3. 3. 9:34

Setting up



NOTE

Each measurement based on the design dimension, so it may differ depending on the measuring method.

When moving your refrigerator



⚠ CAUTION

- To prevent floor damage, be sure the front adjusting legs are in the up position (above the floor).
  Refer to "Leveling the refrigerator" on page 29.

DA68-02981N-00.indb 20 2015. 3. 3. 9:34

Flooring



For proper installation, you must place this refrigerator on a level, hard surface that is the same height as the rest of the floor. This surface should be strong enough to support a fully loaded refrigerator.
To protect the finish of the flooring during installation, cut a large section of the cardboard carton and place it under the refrigerator where you are working.
When moving the refrigerator, you need to pull and push it straight forwards or back. Do not wiggle it from side to side.

⚠ CAUTION

- When installing, servicing or cleaning behind the refrigerator, be sure to pull the unit straight out and push back in straight after finishing.

Important: Make sure that you can easily move your refrigerator to its final location by measuring doorways (both width and height), thresholds, ceilings, stairways, etc. The following chart details the exact height and depth of this Samsung Side by Side Refrigerator.

NOTE

- Make sure you disconnect the water supply line BEFORE removing the freezer door.
  To avoid damage, refer to "2. Separate the water supply line from the refrigerator" in the manual (page 25).

DA68-02981N-00.indb 21 2015. 3. 3. 9:34

Setting up

Setting up the refrigerator

Installing the handlesr

Important: If you need to remove the refrigerator's doors to move it into place, install the handles after you put the doors back on.
Take the handles out of the right side door.



NOTE

- The handles are included in the package.

DA68-02981N-00.indb 22 2015. 3. 3. 9:34

How to install the handles

Orient each handle so that the end with the sticker attached is at the top and the holes with the tightening screws are facing each other.
Then, follow the directions below to install each handle.











Fix the handles to the doors by sliding them down firmly.





DA68-02981N-00.indb 23 2015. 3. 3. 9:34

Setting up

Removing the refrigerator doors

If your entrance won't allow the refrigerator to pass easily through it, you can remove the refrigerator doors.
To remove the doors, follow the steps below.
If you do not need to remove the doors, go to "Leveling the refrigerator" on page 29.

Tools you'll need



Philips Screwdriver



Flat-blade Screwdriver



Socket Wrench
(13/32") (10 mm)

1. Removing the Front Leg Covers



Open both the freezer and refrigerator doors.
Unscrew the three screws holding the front leg cover in place by turning them counter-clockwise.
When the screws are loose, remove the front leg cover.

DA68-02981N-00.indb 24 2015. 3. 3. 9:34

2. Separate the water supply line from the refrigerator



Remove one or two water lines, depending on the model, by pressing each coupler (1) and pulling the water lines (2) away.

NOTE

- Your refrigerator may have one or two water lines, depending on the model. If it has two, the lines are different colors. Make sure you match the colors when you re-attach them.

⚠ CAUTION

- Do not cut the water line. Gently separate it from the coupler.

3. Remove the freezer door

A few things to mention first.

- Make sure that you lift the door straight up so the hinges are not bent or broken.
- Be careful not to pinch the water tubing and wire harness on the door.
- Place doors on a protected surface to prevent scratching or damage.
- Is necessary, have two people disassemble the doors.



1. With the Freezer door closed, remove the upper hinge cover (1) using a screwdriver, and then disconnect the wires by gently pulling them apart (2).

NOTE

- Be careful not to damage the sensor harness with the hinge cover.

DA68-02981N-00.indb 25 2015. 3. 3. 9:34

Setting up



2. Remove the hinge bolts (3) with a 13/32" (10 mm) Socket Wrench. Remove the ground screw (4) by turning it counter-clockwise. Take off the upper hinge (5) in the direction of the arrow. Take care that the door does not fall on you.



3. Open the Freezer door, and then remove the door from the lower hinge (6) by carefully lifting it up (7).



4. Remove the lower hinge (8) from the lower hinge bracket (9) by lifting the lower hinge up in the direction of the arrow.

⚠ CAUTION

- Make sure to put the water line through the lower hinge before assembling it.

DA68-02981N-00.indb 26 2015. 3. 3. 9:34

4. Remove the fridge door



1. With the door closed, remove the upper hinge cover (1) using a screwdriver.



2. Remove the hinge bolts (2) with a 13/32" (10 mm) Socket Wrench.
Remove the ground screw (3) by turning it counter-clockwise.
Take off the upper hinge (4) in the direction of the arrow.
Take care that the door does not fall on you.

⚠ CAUTION

- Do not remove the sensor assembled in the right upper hinge cover.



3. Remove the door from the lower hinge (6) by lifting the door (7).

DA68-02981N-00.indb 27 2015. 3. 3. 9:34

Setting up



4. Remove the lower hinge (8) from the lower hinge bracket (9) by lifting the lower hinge up in the direction of the arrow.

Re-attaching the Fridge Door

To re-attach the fridge door, replace parts in reverse order.

Re-attaching the Freezer Door

To re-attach the freezer door, replace parts in reverse order.

Re-attaching the Water Supply Lines



1. The Water Lines must be fully Inserted into the center of the transparent coupler to prevent water leakage from the dispenser.
2. Insert the 2 clips in the install pack as shown below, and then confirm that each clip holds the line firmly.

⚠ CAUTION

- Make sure the color of the water lines match.

DA68-02981N-00.indb 28 2015. 3. 3. 9:34

Leveling the refrigerator

Make sure the refrigerator is level so that you can make final adjustments.
Use a level to test if the refrigerator is level both side to side and back to front.
If the refrigerator is not level, you will not be able to get the doors perfectly even, which may cause moisture condensation and increased energy bills.

NOTE

- The front of the refrigerator is also adjustable.

Before levelling the refrigerator, remove the front leg cover.



Open both the freezer and refrigerator doors.
Unscrew the three screws holding the front leg cover in place by turning them counter-clockwise.
When the screws are loose, remove the front leg cover.

When the Freezer part is lower than the Fridge part.

Insert a flat-blade screwdriver into a slot on the Freezer Leg, then turn it clockwise.

When the Fridge part is lower than the Freezer part.



Insert a flat-blade screwdriver into a slot on the Fridge Leg, then turn it clockwise.

NOTE

- Refer to the next section for the best way to make very minor adjustments to the doors.

DA68-02981N-00.indb 29 2015. 3. 3. 9:34

Setting up

Making minor adjustments between doors

A level refrigerator is necessary for getting the doors perfectly even.
Make sure your refrigerator is level before you begin.
If you need help leveling, review the previous section on leveling the refrigerator.



The process for adjusting each door is the same.
Open the doors and adjust them, one at a time, as follows:



1. Unscrew the nut (1) from the lower hinge until it reaches the upper end of the bolt (2).

NOTE

- When you release the nut (1), make sure that you use the hex wrench provided (3) to loosen the bolt (2) in a counter-clockwise ( ) direction.
  You should then be able to unscrew the nut (1) with your fingers.



2. Adjust the height difference between the doors by turning the bolt (2) clockwise ( ) or counter clockwise ( ).

NOTE

- When you turn clockwise ( ), the door will move up.

DA68-02981N-00.indb 30 2015. 3. 3. 9:34



3. After adjusting the doors, turn the nut (1) clockwise ( ) until it reaches the lower end of the bolt, then tighten the bolt again with the wrench (3) to fix the nut in place (1).

NOTE

- If you do not secure the nut firmly, the bolt may release.

Installing the water dispenser line

A water dispenser is one of the helpful features on your new Samsung Refrigerator.
To help promote better health, the Samsung water filter removes unwanted particles from your water.
However, it does not sterilize or destroy microorganisms.
You may need to purchase a water purifying system to do that.
The water line also connects to the ice maker.
For the ice maker to operate properly, water pressure of 20 ~ 125 psi (138 ~ 862 kPa) is required.
If the refrigerator is installed in an area with low water pressure (below 20 psi), you can install a booster pump to compensate for the low pressure.
After you have connected the water line, make sure the water storage tank inside the refrigerator is properly filled.
To do this, press the water dispenser lever until water runs from the water dispenser.

NOTE

- Water line installation kits are available at extra cost from your dealer. We recommend using a water supply kit that contains copper tubing.

DA68-02981N-00.indb 31 2015. 3. 3. 9:34

Setting up

Connecting to the water supply line



1. First, shut off the main water supply line and turn the ice-maker off.

NOTE

- The refrigerator should NOT be plugged in at this point.

2. Locate the nearest cold water drinking water line.
3. Install the pipe clamp and shut off valve.
4. Connect the water line installation kit to the shut off valve.

Connecting the water supply line to the refrigerator

There are several items that you need to purchase to complete this connection.
You may find these items sold as a kit at your local hardware store.

Use Copper Tubing	1/4" (6.35 mm) copper tubing
	1/4" (6.35 mm) compression nut (1pc)
	Ferrule (2pc)
Use Plastic Tubing	1/4" (6.35 mm) plastic tubing → Molded end (Bulb)
	1/4" (6.35 mm) compression nut (1pc)

DA68-02981N-00.indb 32 2015. 3. 3. 9:34



1. Connect the household water line to the assembled compression fitting.

- If you are using copper tubing, slip the compression nut (B) (not supplied) and ferrule (not supplied) on the copper tubing (not supplied) as shown.
- If you are using plastic tubing (B), insert the molded end (Bulb) of the plastic tubing (B) into the compression fitting.

⚠ CAUTION

- Do not use plastic tubing (B) without the molded end (Bulb).

2. Tighten the compression nut (B) onto the compression fitting.
Do not over-tighten the compression nut (B).

3. Turn the water on and check for any leaks inside the refrigerator, around the water filter, and in any connection areas. If you find water drops or leaks, turn off the main water supply.
If the leaks are in the connection areas, check the connections and, if necessary, tighten. If there are leaks in the refrigerator, check the water filter and confirm it is in the locked position.
Turn on the water supply and check for leaks again.

4. Plug in the refrigerator.

DA68-02981N-00.indb 33 2015. 3. 3. 9:34

Setting up

5. Flush 3 gallons of water through the filter before drinking or using the water from the refrigerator.
   (Flush approximately 6 minutes.)
   This will clean the water supply system and remove air from the lines.

To flush, press the Water button, and then press a large glass or cup against the water dispenser lever. Fill the glass, empty it into the kitchen sink after it is filled, and then repeat.

NOTE

- Additional flushing may be required in some households.

6. Open the refrigerator door and make sure there are no water leaks coming from the water filter.

NOTE

- After you turn on the refrigerator, let the ice maker make ice for 1 to 2 days.
  Over that period of time, throw out the first 1 or 2 buckets of ice the ice maker makes to ensure all impurities have been removed from the water line.
- Only connect the water line to a drinkable water source.
- If you have to repair or disassemble the water line, cut off 1/4" (6.35 mm) of the plastic tubing to make sure you get a snug, leak-free connection.
- You can test the water line quickly using a paper cup. Under normal conditions, the water dispenser can fill a 5.75 oz. (170 cc) cup in about 10 seconds.

DA68-02981N-00.indb 34 2015. 3. 3. 9:34

Completing the set up

Now that you have your new refrigerator installed in place, you are ready to set up and enjoy the features and functions of the appliance.
By completing the following steps, your refrigerator should be fully operational.

1. Make sure your refrigerator is in an appropriate location with reasonable clearance between it and the wall. Refer to installation instructions in this manual.
2. Once the refrigerator is plugged in, make sure the interior light comes on when you open the doors.
3. Set the Temperature control to the coldest temperature and wait for an hour.
   The freezer will get slightly chilled and the motor will run smoothly.
   Reset the refrigerator and freezer to the temperatures you want.
4. After you plug the refrigerator in, it will take a few hours to reach the appropriate temperature.
   You can store food and drinks in the refrigerator after the temperature is sufficiently cool.

NOTE

- If condensation or water drops appear on both sides of the fridge door's central part, turn the Energy Saver mode off after removing the condensation.
  (See the explanation of the Energy Saver button in "Using the control panel" on page 38.)

Preventing Power Cord Damage



To prevent power cord damage, fix any excess power cord to the top rear of the refrigerator as shown in the illustration below.

DA68-02981N-00.indb 35 2015. 3. 3. 9:34

Operating

Checking the control panel



01 Freezer / Energy Saver (3 sec)	Press the **Freezer** button to set the freezer temperature between cold and coldest. Press Freezer button for several times to activate the Power Freeze icon which speeds up the freezing process in the freezer. This can be helpful if you need to quickly freeze items that spoil easily or if the temperature in the freezer has warmed dramatically (For example, if the door was left open). If you need to freeze a large amount of food, activate the Power Freeze function at least 20 hours before you put the food into the freezer. Press and hold the **Freezer** button for 3 seconds to activate the Energy Saver function for better energy efficiency. If condensation occurs on the doors, turn the Energy Saver function off.

DA68-02981N-00.indb 36 2015. 3. 3. 9:34

02 Fridge / Control Lock (3 sec)	Press the **Fridge** button to set the Fridge temperature between cold and coldest. Press and hold the Fridge button for several times to activate the Power Cool function which speeds up the cooling process in the refrigerator. If you press and hold the **Fridge** button for 3 seconds, all buttons will be locked and the dispenser pad will not work.
03 Ice / Ice Maker Off (3 sec)	Press the **Ice** button to select cubed ice or crushed ice. Press and hold the **Ice** button for 3 seconds to turn the ice making function off. Press and hold the Ice button again for 3 seconds to turn the ice making function back on.
04 Water / Reset Filter (3 sec)	Press the **Water** button to turn the water dispenser on. Press and hold the **Water** button for 3 seconds after changing the filter to reset the water filter indicator.

NOTE

- To deactivate the secondary functions (such as Ice Off and Control Lock), press and hold the corresponding button again for 3 seconds.

DA68-02981N-00.indb 37 2015. 3. 3. 9:34

Operating

Using the control panel

Freezer / Fridge (Temperature adjustment)



Press the **Freezer** or **Fridge** button until the desired temperature is set.
For a lower temperature, press the **Freezer** or **Fridge** button until more LEDs light (colder).
For a higher temperature, press the **Freezer** or **Fridge** button until fewer LEDs light (less cold).
Each time you press the **Freezer** or **Fridge** button, the temperature indicator changes in the order shown below.

Power Freeze	This icon lights when you activate the Power Freeze function. Power Freeze function generates cool air for 50 hours continuously, chilling the freezer more quickly. This function is useful when you need to decrease the temperature in the freezer quickly or to make more ice rapidly. When the freezer is cold enough or you have enough ice, just press the Freezer button again to cancel the Power Freeze function. **NOTE** • When you use this function, the energy consumption of the refrigerator may increase. Remember to turn it off when you do not need it and return the freezer to your original temperature setting.
Energy Saver	This icon lights when you activate the Energy Saver function. The Energy Saver function is automatically set to "ON" when power is supplied to the Refrigerator. If condensation occurs on the doors, turn the Energy Saver function off.

DA68-02981N-00.indb 38 2015. 3. 3. 9:34

 Control Lock	This icon lights when you activate the Lock function. When the Lock icon is lit, all the panel buttons, including the Ice button and the dispensers, are locked and de-activated. Press and hold the Fridge button for 3 seconds to turn Lock off and re-activate the panel buttons.
 Filter Indicator	This icon turns red when you need to change the filter, usually after the refrigerator has dispensed about 300 gallons of water (or after about 6 months). The icon will blink red for several seconds when you open or close the door. The filter Indicator will be Off when you initially insert the water filter.
 Power Cool	This icon lights when you activate the Power Cool function. Power Cool function is great for a quick fridge cool down. If you activate the Power Cool function, the inside temperature of the Fridge decreases for about two and a half hours. When you want to turn Power Cool off, press Fridge button again.
 Cubed  Crushed	Enjoy cubed or crushed ice by selecting your preference from the digital control panel. The ice type light indicates the type of ice that is currently chosen.
 Ice Off	This icon lights when you activate the Ice Off function. When the Ice Off icon is lit, the ice maker is turned off.
 Water	This icon lights when you activate the Water function. When the Water icon is lit, the water dispenser is on.

DA68-02981N-00.indb 39 2015. 3. 3. 9:34

Operating

Display Off	To conserve energy, the Panel Display turns off automatically under the following conditions: When no button has been pressed, when no doors have been opened, or when no Dispenser Lever has been pushed for a period of time. However, the icon indicating your Water or Cubed / Crushed selection, stays on. When you press a button, open a door, or push a Dispenser Lever, the Panel Display turns on again. Except for the Water and Ice buttons, all function buttons will become operational after you remove your finger from the button you are currently pressing.

⚠ CAUTION

- If the refrigerator's water supply line is not connected and water is not being supplied to the refrigerator, the refrigerator will make unusual noises if the ice maker is on or if you push the water dispenser lever.
  To stop the noises, press the Ice button until the Ice Off icon lights up (at least 3 seconds) indicating that the ice maker is off.
  If the water line is connected, and your refrigerator is making unusual noises, see if the water supply valve on the line connected to your refrigerator is closed, preventing water from flowing into the refrigerator.
  If the valve is closed, open the valve.

Cooling Off Mode
(Demo Mode/Shop Mode)

NOTE

- Cooling Off mode (also called Shop mode or Demo mode) is designed for use by retailers when they display refrigerators on the shop floor.
  In Cooling Off mode, the refrigerator's fan motor and lights work normally, but the compressors do not run, and the refrigerator and freezer do not get cold.
- To start Cooling Off mode, Press and hold the Freezer button, the Ice button and the Fridge button for 5 seconds during normal operation.
  The refrigerator chime sounds and Animaiton(Freezer/Fridge Temperature Indicator moveing) appears on the display.

DA68-02981N-00.indb 40 2015. 3. 3. 9:34

⚠ CAUTION

- If your refrigerator appears to be working, but it is not cooling, and the Freezer and Fridge Temperature Indicators are moving, the Fridge is in Cooling Off mode.
  To cancel Cooling Off mode, follow the directions above.

Using the ice and cold water dispenser



No Ice : Select this if you want to turn the ice maker off.



Using the water dispenser

Press the Water button on the control panel.
Place your glass under the water outlet, and then push against the dispenser pad until you hear a click.
Make sure the glass is in line with the dispenser to prevent the water from splashing out.

DA68-02981N-00.indb 41 2015. 3. 3. 9:34

Operating

To get colder water

- The dispensed water is cool, not icy cold.
- When you want colder water, dispense ice into your glass first before filling it with water to prevent water from splashing out.

Using the ice dispenser

Press the Ice button to select the type of ice you want.
Place your glass under the ice outlet, and then push gently against the dispenser pad.
Make sure the glass is in line with the dispenser to prevent the ice from bouncing out.
When cubed ice is selected after you have dispensed crushed ice, a small amount of residual crushed ice might be produced.

DA68-02981N-00.indb 42 2015. 3. 3. 9:34

Storing food

The Samsung Side-By-Side Refrigerator has been designed to provide you with maximum space saving features and functions.
Here are some of the customized compartments we have created to keep your food fresher, longer.
Important : To prevent odors from penetrating the ice in the ice maker, store all food securely in wraps or containers that are as airtight as possible.



⚠ CAUTION

- Because the following operating instructions cover various models, the instructions for your refrigerator may differ slightly from the instructions in this manual.

DA68-02981N-00.indb 43 2015. 3. 3. 9:34

Operating

Storing Food in the Freezer

01 Xtra Space	Can be used for frozen foods such as pizza, pasta, burritos, and fajitas. To prevent odor penetration of the ice, stored food should be wrapped securely.
02 Door Bins	Can be used for small packages of frozen food.
03 Wire Shelf	Can be used to store frozen food.
04 Freezer Drawer	Best used for storing meat or other frozen items. For safe keeping, stored food should be wrapped securely in foil or other suitable wrapping materials or containers.

Storing Food in the Fridge

05 Fruit & Vegetable Drawer	Used to preserve the freshness of your stored vegetables and fruits.
06 Door Bin	Designed to handle large, bulky items such as gallons of milk or other large bottles and containers.
07 Glass Shelf	Designed to be crack-resistant. They can be used to store food and drinks. Circular marks on the glass surface are a normal phenomenon and can usually be wiped clean with a damp cloth.
08 Dairy Bin	Can be used to store smaller dairy items like butter or margarine, yogurt, or cream-cheese bricks.

NOTE

- Bottles should be stored tightly together so that they do not tip and fall out when the refrigerator door is opened.

⚠ WARNING

- If you plan to go away for a significant time, empty the refrigerator and turn it off. Wipe the excess moisture from the inside of the appliance and leave the doors open. This helps keep odor and mold from developing.
- If the refrigerator is not to be used for a long period of time, pull out the power plug.
  - Deterioration of the power cord insulation may cause fire.

DA68-02981N-00.indb 44 2015. 3. 3. 9:34

Removing the freezer/fridge accessories



1. Door Bins
To remove, firmly grab the door bin with both hands and lift it up gently.



2. Shelves
Pull the shelf out as far as it goes. Then lift it up and remove it.
(Wire Shelf/Glass Shelf)



3. Drawer
To remove, pull the drawers out as far as they go, and then lift up slightly and pull.
(Drawer/Fruit & Vegetable Drawer)

DA68-02981N-00.indb 45 2015. 3. 3. 9:34

Operating

Cleaning the refrigerator

Caring for your Samsung Side-By-Side Refrigerator prolongs the life of your appliance and helps keep it odor and germ-free.

Cleaning the Interior



Clean the inside walls and accessories with a mild detergent, and then wipe dry with a soft cloth.
You can remove the drawers and shelves for a more thorough cleaning.
Just make sure to dry them before putting them back into place.

Cleaning the Exterior





Wipe the digital panel and display panel with a clean, soft cloth.
Spray water onto the cleaning cloth instead of spraying directly on the surface of the refrigerator. This helps ensure an even distribution of moisture on the surface.
The doors, handles, and cabinet surfaces should be cleaned with a mild detergent, and then wiped dry with a soft cloth.
To keep your appliance looking its best, the exterior should be polished once or twice a year.

⚠ WARNING

- Do not use Benzene, Thinner, or Clorox (bleach)™ for cleaning.
  They may damage the surface of the appliance and can create a risk of fire.

DA68-02981N-00.indb 46 2015. 3. 3. 9:34

Cleaning the rubber door seals



If the rubber door seals are dirty, the doors may not close properly, and the refrigerator will not operate efficiently. Keep the door seals free of grit or grime by cleaning the doors with a mild detergent and damp cloth.
Wipe dry with a clean, soft cloth.

⚠ CAUTION

- Do not spray the refrigerator with water while it is plugged in, as it may cause an electric shock.
  Do not clean the refrigerator with benzene, thinner, or car detergent as there is a risk of fire.

Changing the LED type lighting

⚠ CAUTION

- Do not disassemble or replace the LED type lighting.
  To change the LED type lighting, contact a Samsung service center.

DA68-02981N-00.indb 47 2015. 3. 3. 9:34

Operating

Changing the water filter

NOTE

- Replace the water filter when the water filter indicator turns red.
  The water filter is located on the bottom right side of the refrigerator.
- To make changing the water filter easier, you may want to shut off the water supply, and then drain any water remaining in the water line by pressing the Water button and then pressing a glass against the water dispenser pad.



1. Turn the water filter 90˚ counter-clockwise.



2. Pull the water filter out of the filter housing.



3. Insert a new water filter into the filter housing.

DA68-02981N-00.indb 48 2015. 3. 3. 9:34



4. Turn the new water filter 90° clockwise.

5. Press and hold the Water button for 3 seconds after changing the filter to reset the filter indicator.
Confirm the indicator turns blue. When you replace the water filter, some water may leak from the water filter housing. Make sure to wipe up any leakage that may have occurred.

DA68-02981N-00.indb 49 2015. 3. 3. 9:34

Operating

Removing residual matter from inside the water supply line after installing a new filter



1. Turn ON the main water supply.
2. Press the Water button on the control panel. Place a cup or glass under the water outlet, and then push the cup or glass against the dispenser pad until you hear a "click".
3. Flush 3 gallons of water through the filter.
   (Flush approximately 6 minutes.)
   This will clean the water supply system and remove air from the lines.
4. Additional flushing may be required in some households.
5. Open the refrigerator door and make sure there are no water leaks coming from the water filter.

NOTE

- A newly installed water filter cartridge may cause water to briefly spurt from the water dispenser.
  This is the result of air getting into the line.
  It poses no problem to the operation of the refrigerator.

DA68-02981N-00.indb 50 2015. 3. 3. 9:34

Food storage tips

Foods	Refrigerator	Freezer	Storage Tips
Dairy products			
Butter	2-3 Weeks	6-9 Months	Wrap or cover tightly.
Milk	1-2 Weeks	Not recommended	Check date code. Most milk and similar products are sold in date-coded cartons that indicate a products's peak freshness. Re-seal with cap or wrap tightly. Do not return unused portions to original container.
Cream Cheese, cheese food, and cheese spread	2-4 Weeks	Not recommended	Check date code. Keep all cheese tightly packed in moisture proof wrap
Hard Cheese (unopened)	3-4 Months	6 Months	
Hard Cheese (opened)	2 Months	Not recommended	
Cottage Cheese	10-15 Days	Not recommended	
Cream	7-10 Days	2 Months	Check date code. Most yogurt, creams, and similar products are sold in date-coded cartons that indicate a product's peak freshness. Re-seal or cover tightly. Do not return unused portions to original container.
Sour Cream	2 Weeks	Not recommended	
Cream Dips (opened)	1 Week	Not recommended	
Yogurt	10-14 Days	Not recommended	Check date code. Keep covered.
Frozen Yogurt	na	2 Months	
Eggs			
Eggs (uncooked)	3-4 Weeks	Not recommended	Check date code. Store eggs in coldest part of refrigerator and in their original container.
Eggs (cooked)	1 Week	Not recommended	Store in covered container
Leftover egg dishes	3-4 Days	Not recommended	Store in covered container

DA68-02981N-00.indb 51 2015. 3. 3. 9:34

Operating

Foods	Refrigerator	Freezer	Storage Tips
Fresh fruits			
Apples	1 Month	Not recommended	If storing in refrigerator, do not wash fruit before storing. Store in moisture resistant bags or containers. Wrap cut fruits. Some fruits darken when refrigerated.
Bananas	2-4 Days	Not recommended	
Peaches, Melons, Pears, Avocados	3-5 Days	Not recommended	
Berries and Cherries	2-3 Days	12 Months	
Apricots	3-5 Days	Not recommended	
Grapes	2-5 Days	na	
Pineapple (un-cut)	2-3 Days	Not recommended	
Pineapple (cut)	5-7 Days	6-12 Months	
Citrus	1-2 Weeks	Not recommended	Store uncovered.
Juice	6 Days	Not recommended	Check date code and re-seal in original container. Do not return unused portions to original container.
Frozen Juice	Thawing only	12 Months	Check date code. Do not re-freeze.
Fish and shellfish			
Fish			
Fatty Fish (mackerel, trout, salmon)	1-2 Days	2-3 Months	Keep in original wrapper and store in coldest part of refrigerator. Package in vapor-proof and moisture proof wrap for freezer. Freeze at 0 °F (or -18 °C). Thaw in refrigerator or check date code. Freeze in original packaging.
Lean Fish (cod, flounder, etc)	1-2 Days	6 Months	
Frozen or Breaded	na	3 Months	
Shellfish			
Shrimp (uncooked)	1-2 Days	12 Months	To freeze, package in vapor-proof and moisture-proof container.
Crab	3-5 Days	10 Months	
Cooked Fish or Shellfish	2-3 Days	3 Months	

DA68-02981N-00.indb 52 2015. 3. 3. 9:34

Foods	Refrigerator	Freezer	Storage Tips
Meat			
Fresh, Uncooked			
Chops	2-4 Days	6-12 Months	Check date code for use. Store in coldest part of refrigerator in original packaging. Package in moisture-proof and vapor-proof container for freezing. Recommended refrigerator temperature 33 ºF to 36 ºF (or 1 ˚C to 2 ˚C) and freezer temperature 0 ºF to 2 ºF (or -18 ˚C to -16 ˚C)
Ground	1 Day	3-4 Months	
Roast	2-4 Days	6-12 Months	
Bacon	1-2 Weeks	1-2 Months	
Sausage	1-2 Days	1-2 Months	
Steak	2-4 Days	6-9 Months	
Poultry	1 Day	12 Months	
Lunch meat	3-5 Days	1 Month	
Cooked			
Meat	2-3 Days	2-3 Months	Check date code for use. Store in coldest part of refrigerator in original packaging. Package in moisture-proof and vapor-proof container for freezing.
Poultry	2-3 Days	4-5 Months	
Ham	1-2 weeks	1-2 Months	

Sources:

American Meat Institute Foundation. 1994. Yellow pages: answers to predictable questions consumers ask about meat and poultry. American Meat Institute Food Marketing Institute. 1999. The food keeper. Food Marketing Institute, Washington, D.C. Freeland-Graves, J.H. and G.C. Peckham. 1996. Foundations of food preparation, 6th ed. Prentice-Hall, Inc. Englewood Cliffs, NJ. Hillers, V.N. 1993. Storing foods at home. Washington State University Cooperative Extension, Pullman, WA. Publ. EB 1205. National Restaurant Association. 2001. Be cool-chill out! Refrigerate promptly. National Restaurant Association Education Foundation¼s International Food Safety Council, Washington, D.C. USDA. 1997. Basics for handling food safely. U.S. Department of Agriculture, Food Safety and Inspection Service, Washington, D.C.

DA68-02981N-00.indb 53 2015. 3. 3. 9:34

Troubleshooting

Problem	Solution
The refrigerator does not work at all or it does not chill sufficiently.	• Confirm that the power plug is properly connected. • Is the temperature control on the display panel set to the correct temperature? Try setting it to a lower temperature. • Is the refrigerator in direct sunlight or located too near a heat source? • Is the back of the refrigerator too close to the wall and therefore keeping air from circulating? • Check if the Cooling Off Mode is on. If the Freezer/Fridge temperature indicator is moving, refer to page 40 to cancel the Cooling Off Mode.
The food in the fridge is frozen.	• Is the temperature control on the display panel set to the correct temperature? Try setting it to a warmer temperature. • Is the temperature in the room very low? • Did you store the food with a high water content in the coldest part of the fridge?
You hear unusual noise or sounds.	• Confirm that the refrigerator is level and stable. • If the refrigerator's water supply line is not connected and water is not being supplied to the refrigerator, the refrigerator will make unusual noises if the ice maker is on or if you push the water dispenser lever. To stop the noises, press the Ice button for at least 3 seconds until the Ice Off icon lights indicating that the ice maker is off. • You hear a ticking sound from inside the refrigerator. This is normal and occurs because various parts in the refrigerator's interior contract or expand in response to temperature changes.
The front corners of the appliance are hot and condensation is occurring.	• Some heat is normal as anti-condensators are installed in the front corners of the refrigerator to prevent condensation. • Is the refrigerator door ajar? Condensation can occur when you leave the door open for a long time.

DA68-02981N-00.indb 54 2015. 3. 3. 9:34

Problem	Solution
Ice is not dispensing.	• Did you wait for 12 hours after installation of the water supply line before making ice? • Is the water line connected and the shut-off valve open? • Did you manually stop the ice making function? Make sure Ice Type is set to Cubed or Crushed. • Is there any ice clumped in the ice maker bucket? • Is the freezer temperature too warm? Try setting the freezer temperature lower.
You can hear water bubbling in the refrigerator.	• This is normal. The bubbling comes from the refrigerant coolant liquid circulating through the refrigerator.
There is a bad smell in the refrigerator.	• Has a food item spoiled? • Make sure that strong smelling food (for example, fish) is wrapped so that it is airtight. • Clean out your freezer periodically and throw away any spoiled or suspect food.
Frost forms on the walls of the freezer.	• Is the air vent blocked? Remove any obstructions so air can circulate freely. • Allow sufficient space between the foods stored for efficient air circulation. • Is the freezer door closed properly?
Water dispenser is not functioning.	• Is the water line connected and the shut-off valve open? • Has the water supply line tubing been crushed or kinked? Make sure the tubing is free and clear of any obstruction. • Is the water tank frozen because the refrigerator temperature is too low? Try selecting a warmer setting on the main display panel.

DA68-02981N-00.indb 55 2015. 3. 3. 9:34

Warranty (USA)

WARRANTY ON SAMSUNG REFRIGERATOR
LIMITED WARRANTY TO ORIGINAL PURCHASER
This Samsung brand product, as supplied and distributed by Samsung Electronics America, Inc. (Samsung) and delivered new, in the original carton to the original consumer purchaser, is warranted by Samsung against manufacturing defects in materials and workmanship for a limited warranty period of:

One (1) year Parts and Labor on Refrigerator
Five (5) years Parts and Labor on sealed Refrigeration system only*
Ten (10) years Parts and Five (5) years Labor on Digital Inverter Compressor
(*Compressor, evaporator, condenser, drier, connecting tubing)

This limited warranty begins on the original date of purchase, and is valid only on products purchased and used in the United States. To receive warranty service, the purchaser must contact Samsung for problem determination and service procedures. Warranty service can only be performed by a Samsung authorized service center. The original dated bill of sale must be presented upon request as proof of purchase to Samsung or Samsung authorized service center.

Samsung will repair or replace any part found to be defective, at our option and at no charge as stipulated herein, with new or reconditioned parts during the limited warranty period specified above. All replaced parts and products become the property of Samsung and must be returned to Samsung. Replacement parts and products assume the remaining original warranty, or ninety (90) days, whichever is longer.

In-home service will be provided during the warranty labor period subject to availability within the contiguous United States. In-home service is not available in all areas. To receive in-home service, the product must be unobstructed and accessible from floor level to service personnel. If during in-home service repair cannot be completed, it may be necessary to remove, repair and return the product. If in-home service is unavailable, Samsung may elect, at our option, to provide for transportation of our choice to and from a Samsung authorized service center. Otherwise, transportation to and from the Samsung authorized service center is the responsibility of the purchaser.

This limited warranty covers manufacturing defects in materials and workmanship encountered in normal, noncommercial use of this product, and shall not apply to the following, including, but not limited to: damage which occurs in shipment; delivery and installation; applications and uses for which this product was not intended; altered product or serial numbers; cosmetic damage or exterior finish; accidents, abuse, neglect, fire, water, lightning or other acts of nature; use of products, equipment, systems, utilities, services,

DA68-02981N-00.indb 56 2015. 3. 3. 9:34

parts, supplies, accessories, applications, installations, repairs, external plumbing and leaks, external wiring, circuit breakers, fuses or connectors not supplied and authorized by Samsung, or which damage this product or result in service problems; incorrect electrical line voltage, fluctuations and surges; customer adjustments and failure to follow operating instructions, cleaning, maintenance and environmental instructions that are covered and prescribed in the instruction book; loss of food due to spoilage; consumable items including filters and light.

THERE ARE NO EXPRESS WARRANTIES OTHER THAN THOSE LISTED AND DESCRIBED ABOVE, AND NO WARRANTIES WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SHALL APPLY AFTER THE EXPRESS WARRANTY PERIODS STATED ABOVE, AND NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR CORPORATION WITH RESPECT TO THIS PRODUCT SHALL BE BINDING ON SAMSUNG. SAMSUNG SHALL NOT BE LIABLE FOR LOSS OF REVENUE OR PROFITS, FAILURE TO REALIZE SAVINGS OR OTHER BENEFITS, OR ANY OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE, MISUSE OR INABILITY TO USE THIS PRODUCT, REGARDLESS OF THE LEGAL THEORY ON WHICH THE CLAIM IS BASED, AND EVEN IF SAMSUNG HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. NOR SHALL RECOVERY OF ANY KIND AGAINST SAMSUNG BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE PRODUCT SOLD BY SAMSUNG AND CAUSING THE ALLEGED DAMAGE. WITHOUT LIMITING THE FOREGOING, PURCHASER ASSUMES ALL RISK AND LIABILITY FOR LOSS, DAMAGE OR INJURY TO PURCHASER AND PURCHASER'S PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF THE USE, MISUSE OR INABILITY TO USE THIS PRODUCT SOLD BY SAMSUNG NOT CAUSED DIRECTLY BY THE NEGLIGENCE OF SAMSUNG. THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT, IS NONTRANSFERABLE AND STATES YOUR EXCLUSIVE REMEDY.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.
To obtain warranty service, please contact Samsung at:

SAMSUNG CUSTOMER CARE CENTER
Samsung Electronics America, Inc. 85 Challenger Road Ridgefield Park, NJ 07660
1-800-SAMSUNG (1-800-726-7864) and www.samsung.com

DA68-02981N-00.indb 57 2015. 3. 3. 9:34

If your refrigerator needs service

Do not hesitate to call any Samsung Authorized Service Center nearby giving them your name, address and telephone number when your product is not functioning properly.

Warranty Information (CANADA)

Limited Warranty for Original Purchaser
This Samsung product is warranted by Samsung Electronics Canada Inc. (hereafter referred to as SECA) against manufacturing defects in material or workmanship for the following periods:

Labor : 1 years (in-home)
Parts : 1 years
Inverter Compressor : 10 years

SECA further warrants that if this product fails to operate properly within the specified warranty period and the failure is due to improper workmanship or defective material, SECA will repair or replace the product at its option.
In-home service is not available in all areas. Contact us to find out if in-home service is currently available in your area by using the contact information at the back of this warranty.

All warranty repairs or part replacements must be performed by a SECA Authorized Service Center. (To find the nearest SECA Service Center, call 1-800-SAMSUNG (7267864) or visit our web site at www.samsung.com/ca)

Obligation to the Original Owner
The original dated sales receipt must be retained by the customer and is the only acceptable proof of purchase.
It must be presented to a SECA Authorized Service Center at the time service is requested before warranty services are rendered. On all carry-in models, transportation to and from the Authorized Service Center is the responsibility of the customer.

DA68-02981N-00.indb 58 2015. 3. 3. 9:34

Exclusions of the Warranty

This warranty does not cover damage due to accident, fire, flood, and/or other Acts of God, misuse, incorrect line voltage, improper installation, improper or unauthorized repairs, commercial use, or damage that occurs during shipping. Customer adjustments which are explained in this owners manual are not covered under the terms of this warranty.
This warranty will automatically be voided for any unit found with a missing or altered serial number.
This warranty is valid only on products purchased and used in the Canada.

Samsung Electronics Canada Inc. 2050 Derry Road West, Mississauga, Ontario L5N 0B9 Canada

Customer Care Center 1-800-SAMSUNG (726-7864)
Customer Care Center Fax. 1-866-436-4617

If you have any questions or comments relating to Samsung products,
please contact the SAMSUNG customer care center.
Samsung Electronics Canada Inc. 2050 Derry Road West, Mississauga, Ontario L5N 0B9
Canada
TEL : 905-542-3535 FAX : 905-542-3835
1-800-SAMSUNG (726-7864)
www.samsung.com/us/support

DA68-02981N-00.indb 59 2015. 3. 3. 9:34

Scan the QR code* or visit
www.samsung.com/spsn
to view our helpful
How-to Videos and Live Shows

* Requires reader to be installed
on your smartphone

Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care center.

COUNTRY	CALL	OR VISIT US ONLINE AT
U.S.A	1-800-SAMSUNG (726-7864)	www.samsung.com/us/support
CANADA	1-800-SAMSUNG (726-7864)	www.samsung.com/ca/support (English) www.samsung.com/ca_fr/support (French)

