# ESSENTIALS
# INSTRUCTION MANUAL

# INTEGRATED FRIDGE FREEZER

**CIFF7015**



currys

# Contents


**Safety Warnings** ..... **4**

**Unpacking** ..... **6**

**Installation** ..... **7**

- Location ..... 7
- Reversing the Door Swing ..... 7
- Installing the Unit into Cabinet ..... 9
- Cleaning Before Use ..... 12
- Before Using Your Unit ..... 12

**Product Overview** ..... **13**

**Operation** ..... **14**

- Switching On Your Unit ..... 14
- Setting Fridge Temperature ..... 14
- Setting Freezer Temperature ..... 14
- Super Mode ..... 14
- Smart Mode ..... 14
- Door Open Alarm (fridge door only) ..... 15
- Noises Inside the Unit! ..... 15
- Tips for Keeping Food in the Unit ..... 15
- Preparations for Freezing ..... 15
- Defrosting Frozen Food ..... 16

**Cleaning** ..... **17**

- Defrosting ..... 17
- Cleaning the Interior and the Exterior of the Unit ..... 17

**Maintenance** ..... **18**

- Changing the Internal Light ..... 18
- Care When Handling / Moving the Unit ..... 18
- Servicing ..... 18
- Switching Off for Long Periods of Time ..... 18
- Condensation ..... 18

**Disposal** ..... **18**

**Specifications** ..... **19**

## Safety Warnings

For your continued safety and to reduce the risk of injury or electric shock, please follow all the safety precautions listed below.

- Read all instructions carefully before using the unit and keep them for future reference.
- Retain the manual. If you pass the unit onto a third party, make sure to include this manual.
- This appliance is intended for indoor household use and similar applications such as:
  - staff kitchen areas in shops, offices and other working environments;
  - farm houses and by clients in hotels, motels and other residential type environment;
  - bed and breakfast type environment;
  - catering and similar non-retail applications.
- Ensure that the plug is easily accessible to enable disconnection from the mains supply.
- If the mains cable is damaged, it must be replaced by the manufacturer, its service agent or a qualified technician in order to avoid a hazard.
- Choose a location for your unit away from heat sources such as radiators or fires as refrigerant and vesicant are burnable.
- The unit must be manoeuvred by a minimum of 2 persons.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children should be supervised to ensure that they do not play with the unit.
- If your unit is fitted with a lock to prevent children being trapped inside, keep the key out of reach and not in the vicinity of the unit.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

- Do not store bottles or glass containers in the freezer compartment. Contents can expand when frozen (fizzy drinks) which may break the bottle and damage your freezer compartment. (If applicable)

**WARNING**

- Keep ventilation openings in the unit enclosure or in the built-in structure clear of obstructions.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not use electrical appliances inside the food storage compartments of the unit, unless they are of the type recommended by the manufacturer.
- Do not damage the refrigerant circuit (The refrigerant is a very environmental-friendly gas but is also combustible. Take care when transporting or moving the unit to ensure that the refrigeration circuit is not damaged. In the event of damage avoid naked flames or ignition sources and ventilate the room in which the unit is placed for a few minutes.)

**WARNING**

IT IS HAZARDOUS FOR ANYONE OTHER THAN AUTHORISED SERVICE PERSONNEL TO CARRY OUT SERVICING OF REPAIRS WHICH INVOLVE THE REMOVAL OF COVERS.


TO AVOID THE RISK OF AN ELECTRICAL SHOCK DO NOT ATTEMPT REPAIRS YOURSELF.

**Thank you** for purchasing your new Currys Fridge Freezer.
We recommend that you spend some time reading this instruction manual in order that you fully understand all the operational features it offers. You will also find some hints and tips to help you resolve any issues.
Read all the safety instructions carefully before use and keep this instruction manual for future reference.

# Unpacking


Remove all items from the packaging. Retain the packaging. If you dispose of it please do so according to local regulations.

The following items are included:


The Main Unit



Fridge Glass Shelf x 3



Salad Bin Cover Shelf


Salad Bin x 1


Upper Fridge Door Shelf x 2



Lower Fridge Door Shelf


Small Freezer Drawer x 2



Large Freezer Drawer


Door Guide x 4


Door Guide Cover x 4


Slider x 4



Slider Cover x 4


Bracket Cover x 2


Short screw x 27


Long screw x 2


Rubber Strip x 1



Instruction Manual

If items are missing or damaged please contact Partmaster (UK only).
Tel: 0344 800 3456 for assistance.

## Location


When selecting a position for your unit you should make sure the floor is flat and firm, and the room is well ventilated with an average room temperature of between 16°C and 38°C. Avoid locating your unit near a heat source, e.g. cooker, boiler or radiator. Also avoid direct sunlight as it may increase the electrical consumption. Extreme cold ambient temperatures may also cause the unit not to perform properly. This unit is not designed for use in a garage or outdoor installation. Do not drape the unit with any covering.

## Reversing the Door Swing


**Tools required:** Philips style screwdriver / Flat bladed screwdriver / Hexagonal spanner

- Ensure the unit is unplugged and empty.
- To take the door off it is necessary to tilt the unit backwards. You should rest the unit on something solid, e.g. a chair just below the top panel.
- All parts removed must be saved to do the reinstallation of the door.
- Do not lay the unit flat as this may damage the coolant system.
- We recommend that 2 people handle the unit during assembly.
- If you want to have the door swing reversed, we recommend that you contact a qualified technician. You should only try to reverse the door yourself if you believe that you are qualified to do so.

1. Unscrew the top hinge that holds the door in place. Lift the upper door and place it on a padded surface to prevent it from scratching.




2. Unscrew the middle hinge. And then lift the lower door and place it on a padded surface to prevent it from scratching.




## *INSTALLATION*


3. Move the bottom hinge from the right side to the opposite side.



4. Move the middle bracket from the left side to the right side. Re-fit the lower door.




5. Re-fit the middle hinge on the left side. Clip the bracket cover on the right side. Test that the bracket cover does not interfere with the opening and closing of the door.




> ⚠ Ensure the lower door is aligned horizontally and vertically, so that the seals are closed on all sides before finally tightening the middle hinge.

6. Unscrew the top hinge pin from the top hinge. Reverse the top hinge and screw back the pin.



7. Re-fit the upper door. Then, re-fit the top hinge on the left side. Use a spanner (not included) to tighten the top hinge if necessary.




Ensure the upper door is aligned horizontally and vertically, so that the seals are closed on all sides before finally tightening the top hinge.


8. With the doors closed, check that the doors are aligned horizontally and vertically and that the seals are closed on all sides before unclipping the bracket cover.

Ensure the bracket cover is removed before installing into any cabinetry.

## Installing the Unit into Cabinet


1. Ensure the size of the cabinet chosen is adequate for the unit.







## INSTALLATION


2. Slowly and carefully push the unit into the cabinet. Ensure that the opening side is as close to the cabinet wall as possible.



3. Screw the door guides to the unit doors with short screws. Insert the sliders into the guides, then fully open and close the unit door and cabinet door to check if the doors can close smoothly and completely.





4. Open both the unit door and the cabinet door. Mark the position of the slider. Take the slider out of the guide and fix the slider on the cabinet door with short screws. Fix the slider cover onto the slider.
5. Remove the door guide from the unit door.
6. Repeat Steps (3) to (5) for the remaining sliders and slider covers.




## INSTALLATION

7. Fit the door guides to the sliders with short screws. Fix the guide covers on the door guides.





> ⚠ After fitting the cabinet doors to the unit doors, ensure the doors open and close without obstruction. Take care to ensure the unit door seals are properly closed.


8. Fix the bottom bracket to the cabinet with long screws.




9. Fix the top bracket to the cabinet with short screws.



10. Insert the rubber strip between the door opening side of the unit and the cabinet wall. Open and close the door to ensure the rubber strip does not interfere with this operation.



11. Fix the 2 middle brackets to the cabinet (one on each side) with short screws. Fix the middle bracket covers on these 2 brackets.




⚠ Ensure the bracket covers do not obstruct the opening and closing of the doors.

## Cleaning Before Use

Wipe the inside of the unit with a weak solution of bicarbonate soda. Then rinse with warm water using a 'wrung-out' sponge or cloth. Wipe completely dry before replacing the shelves, drawers and salad bin. Clean the exterior of the unit with a damp cloth.


If you require more information refer to the **Cleaning** section.

⚠
- **Before Plugging in YOU MUST**
  Check that you have a socket which is compatible with the plug supplied with the unit.
- **Before Turning On!**
  Do not turn on until two hours after moving the unit. The coolant fluid needs time to settle.

## Before Using Your Unit


Before placing any food in your unit, turn it on and wait for 24 hours, to make sure it is working properly and to allow it time to fall to the correct temperature. Your unit should not be overfilled.

# Product Overview




# Operation

## Switching On Your Unit




1. Connect the mains cable to the mains socket. The internal temperature of your unit is controlled by an electronic control panel.
2. Press and hold the **Adjust** button for 5 seconds to turn on or off the unit.
3. The unit may not operate at the correct temperature if it is in a particularly hot or a particularly cold room, or if you open the doors often.
4. To ensure that the unit is cool enough to sufficiently chill your food, wait 24 hours before filling it with food.
5. If you are concerned that your unit is not being kept cold enough and wish to check the temperature, you will need a special fridge/freezer thermometer. These are available from most supermarkets and hardware shops. Place the thermometer in either the fridge or freezer compartment and leave overnight. The correct temperature for the fridge compartment should be at the recommended 8°C or lower. The correct temperature for the freezer compartment should be -18°C or lower.




## Setting Fridge Temperature

- Press the **Mode** button repeatedly to select the fridge temperature setting. The fridge temperature setting indicators (1-5) will illuminate.
- Press the **Adjust** button repeatedly to set temperature for the fridge compartment. Position 3 is the recommended setting when operating at normal room temperature. Bear in mind that the lower the number, the lower the temperature. Please adjust according to the environment.

## Setting Freezer Temperature

The freezer compartment temperature is automatically controlled at around -18°C.

## Super Mode

- Press the **Mode** button repeatedly to select the Super Mode. The Super indicator will illuminate.
- Temperature in the freezer compartment will be quickly lowered.
- To switch off, press the **Mode** button repeatedly to unselect the Super Mode. The Super indicator will extinguish. Otherwise, the original temperature will automatically restore after 54 hours.

## Smart Mode

- Press the **Mode** button repeatedly to select the Smart Mode. The Smart indicator will illuminate.
- Temperature in the unit will self-adjust according to the ambient temperature.
- To switch off, press the **Mode** button repeatedly to unselect the Smart Mode.

## Door Open Alarm (fridge door only)

Alarm will sound when the upper fridge door is left open for 90 seconds and it will not stop sounding until the door is closed.

## Noises Inside the Unit!

You may notice that your unit makes some unusual noises. Most of these are perfectly normal, but you should be aware of them!


These noises are caused by the circulation of the refrigerant liquid in the cooling system. It has become more pronounced since the introduction of CFC free gases. This is not a fault and will not affect the performance of your unit. This is the compressor motor working, as it pumps the refrigerant around the system.

## Tips for Keeping Food in the Unit

- Cooked meats/fishes should always be stored on a shelf above raw meats/fishes to avoid bacterial transfer. Keep raw meats/fishes in a container which is large enough to collect juices and cover it properly. Place the container on the lowest shelf.
- Leave space around your food, to allow air to circulate inside the compartments. Ensure all parts of the unit are kept cool.
- To prevent transfer of flavours and drying out, pack or cover the food separately. Fruit and vegetables do not need to be wrapped.
- Always let pre-cooked food cool down before you put in the unit. This will help to maintain the internal temperature of the unit.
- To prevent cold air escaping from the unit, try to limit the number of times you open the doors. We recommend that you only open the doors when you need to put food in or take food out.

## Preparations for Freezing

- Use quality food and handle it as little as possible. Freeze food in small quantities as it freezes faster, takes less time to defrost and enables you to control the quantity you need better.
- Leave cooked food to cool completely. Chill food before freezing if possible.
- Consider how you will want to cook the food before freezing it.
- Don't freeze food in metal containers if you may want to microwave it straight from the freezer.
- Use special freezer bags, freezer film, polythene bags, plastic containers, and aluminium foil (heavy duty grade only). If in doubt, double wrap your food. Don't use aluminium foil for acidic foods, e.g. citrus fruits. Don't use thin cling film, glass, or used food containers without cleaning.
- Exclude as much air from the container as possible. You could buy a special vacuum pump which sucks excessive air out of the packaging.
- Leave a small amount of air space when freezing liquids to allow expansion.
- You can use the space in the freezer most efficiently if you freeze liquids (or solids with liquids, e.g. stew) in square blocks. This is known as "Preforming". Pour the liquid into a polythene bag which is inside a square sided container. Freeze it, and then remove it from the container and seal the bag.



- Label your frozen foods as they will look the same when in frozen state. Use special fridge freezer tapes, labels and pens with different colours. This allows you to easily organise and to effectively use the freezer. Write the contents and date; otherwise the frozen food might exceed the storage time and this could cause food poisoning. Please refer to your food packaging for the recommended storage time.
- You may also add the weight and cooking notes, e.g. "defrost first", "cook from frozen" and keep a separate log of what is in each drawer. This will save opening the door and searching around unnecessarily.

## Defrosting Frozen Food

1. Take the frozen food out from the freezer compartment and uncover the frozen food. Let it defrost at room temperature. Don't forget that defrosting in a warm area encourages the growth of bacteria and low temperature cooking may not destroy dangerous bacteria.
2. Drain off and throw away any liquid lost during defrosting.
3. Always make sure there are no ice-crystals in the food before cooking, particularly with meat. These crystals indicate that the food has not fully defrosted.
4. Cook food as soon as possible after defrosting.
5. Many microwaves and ovens have a defrost setting. To avoid bacterial build up, only use these if you intend to cook the food immediately afterwards.



Never re-freeze anything that has been defrosted out unless you cook it again, to kill off harmful bacteria. Never re-freeze defrosted shellfish. Re-seal packs properly after removing items. This prevents drying or freezer-burn and a build up of frost on any remaining food.

# Cleaning

## Defrosting

Frost may build up in the freezer compartment after the unit has been used for a period of time. Scrape away the frost using a plastic scraper (not included).



Do not use a metal or sharp instrument to scrape away the frost, nor should you use any electrical appliances to aid defrosting.

We recommend that defrosting should be carried out when the frost layer builds up to 10 mm. Choose a time when the stock of frozen food is low, follow these procedures:


1. Take out the food, turn the unit off at the mains supply and leave the door open. Ideally, the frozen food should be put into another freezer. If this is not possible, wrap the food in several sheets of newspaper or large towels and then a thick blanket to keep it cool.
2. Place a dry towel on the edge of the compartment shelf. Scrape away the frost using a plastic scraper. Defrosting the remaining frost can be speeded up by placing a bowl of hot water inside the freezer compartment and closing the door. As the solid frost loosens, scrape it away with the plastic scraper.
3. When defrosting is complete, clean your unit's interior and exterior.

## Cleaning the Interior and the Exterior of the Unit

- Remove all the shelves, drawers and salad bin before cleaning.
- Wipe the inside of the unit with a weak solution of bicarbonate soda and then rinse with warm water using a sponge or cloth. Wipe completely dry before replacing the shelves and drawers.
- Use a damp cloth to clean the exterior, and then wipe with a standard furniture polish. Make sure that the door is closed to prevent the polish from getting on the magnetic door seal or inside the unit.
- The grille of the condenser at the back of the unit and the adjacent components can be vacuumed using a soft brush attachment.

# Maintenance

## Changing the Internal Light



1. Before replacing the light bulb, always switch off the unit, then disconnect the mains supply.
2. Remove the screw of the light bulb cover.
3. Remove the old light bulb by unscrewing in an anti-clockwise direction.
4. Replace with a new light bulb.
5. Refit the light bulb cover. Reconnect the unit to the mains supply and switch on the unit.

## Care When Handling / Moving the Unit

Hold the unit around its sides or base when moving it.

## Servicing

The unit should be serviced by an authorised engineer and only genuine spare parts should be used. Under no circumstances should you attempt to repair the unit yourself. Repairs carried out by inexperienced persons may cause injury or serious malfunction. Contact a qualified technician.

## Switching Off for Long Periods of Time

When the unit is not in use for a long period of time, disconnect it from the mains supply, empty all food and clean the unit, leaving the door ajar to prevent unpleasant smells.

## Condensation

Condensation may appear on the outside of the unit. This may be due to a change in room temperature. Wipe off any moisture residue. If the problem continues, please contact a qualified technician for assistance.

# Disposal

Old units still have some residual value. An environmentally friendly method of disposal will ensure that valuable raw materials can be recovered and used again. The refrigerant used in the unit and insulation materials require special disposal procedures. Ensure that none of the pipes on the back of the unit are damaged prior to disposal.

Up to date information concerning options of disposing of your old unit and packaging from the new one can be obtained from your local council office.

When disposing of an old unit break off any old locks or latches and remove the doors as a safeguard.

# Specifications

| | |
|---|---|
| **Model** | **CIFF7015** |
| **Appliance Category** | Category 7 (Refrigerator – Freezer) |
| **Overall Dimension (H x W x D)** | 1770 x 540 x 540 mm |
| **Fresh Food Storage Compartment Volume** | 181 L |
| **Frozen Food Storage Volume** | 63 L ✳ *** |
| **Defrosting Type** | Manual Defrost |
| **Climate Class** | N, ST |
| This appliance is intended to be used at an ambient temperature between 16°C and 38°C. | |
| **Storage Temperature** | Freezer: ≤–18°C<br>Fridge: 0-8°C, average ≤4°C |
| **Energy Consumption** | 0.720 kWh / 24 hours |
| Energy consumption **262 kWh per year**, based on standard test results for 24 hours.<br>Actual energy consumption will depend on how the appliance is used and where it is located. | |
| **Airborne Acoustical Noise** | 42 dB |
| **Energy Grading** | A+ |
| **Temperature Rise** | 15 hours |
| **Freezing Capacity** | 2.9 kg / 24 hours |
| **Rated Voltage** | 220-240V~ |
| **Rated Current** | 0.75 A |

Features and specifications are subject to change without prior notice.

KNOWHOW
Lifetime support for Currys PC World customers

For general information about this appliance
and handy hints and tips, please visit
**www.knowhow.com/knowledgebank** or call **0344 5611234**.

Partmaster.co.uk

Visit Partmaster.co.uk today for the easiest way to buy electrical spares and accessories. With over 1 million spares and accessories available we can deliver direct to your door the very next day. Visit www.partmaster.co.uk or call 0344 800 3456 (UK customers only) Calls charged at National Rate.



The symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.
For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.

DSG Retail Ltd. (co. no. 504877)
1 Portal Way, London, W3 6RS, UK

IB-CIFF7015-170329V4