

User Manual

Freezer/Refrigerator

HVF325DW
HVF325DS
HVF325DC

EN

Haier

Thank You

Thank you for purchasing a Haier Product.

Please read these instructions carefully before using this appliance. The instructions contain important information which will help you get the best out of the appliance and ensure safe and proper installation, use and maintenance.

Keep this manual in a convenient place so you can always refer to it for the safe and proper use of the appliance.

If you sell the appliance, give it away, or leave it behind when you move house, make sure you also pass this manual so that the new owner can become familiar with the appliance and safety warnings.

WARNING: Risk of fire/flammable material. The symbol indicates there is a risk of fire since flammable materials are used. Take care to avoid causing a fire by ingniting flammable material.



Manufacture: Qingdao Haier Special Icebox Co., Ltd.
Address : Haier Garden, Qianwangang Road,Economic Development Zone, Qingdao 266555, Shandong, P.R.China

www.haier.com.au
www.haier.co.nz

Content

1 - Safety 4

2 - Intended Use 11

3 - Product Description 12

4 - Control panel 13

5 - Use 14

6 - Energy saving 17

7 - Equipment 17

8 - Care and Cleaning 18

9 - Troubleshooting 20

10 - Installation 23

11 - Technical Data 27

1 - Safety

Before switching on the appliance for the first time, read the following safety hints!

WARNING!

Before first use

- Make sure there is no transport damage.
- Remove all packaging and keep out of children´s reach.
- Wait at least six hours before installing the appliance in order to ensure the refrigerant circuit is fully efcient.
- Handle the appliance always with at least two persons because it is heavy.

Installation

- The appliance should be placed in a well-ventilated place. Ensure a space of at least 10 cm above and around the appliance.
- **WARNING**: Keep ventilation openings, in the appliance or in the in-built structure, clear of obstruction.
- Never place the appliance in a damp area or location where it might be splashed with water. Clean and dry water splashes and stains with a soft clean cloth.
- Do not install the appliance in direct sunlight or in the near of heat sou--rces (e.g. stoves, heaters).
- Install and level the appliance in an area suitable for its size and use.
- Make sure that the electrical information on the rating plate agrees with the power supply. If it does not, contact an electrician.
- The appliance is operated by a 220-240 VAC/50 Hz power supply. Abnormal voltage fuctuation may cause the appliance to fail to start, or damage to the temperature control or compressor, or there may be an abnormal noise when operating. In such case, an automatic regular or shall be mounted.
- Do not use multi-plug adapters and extension cables.
- **WARNING**: Do not locate multiple portable socket outlets or portable power supplies at the rear of the appliance.
- **WARNING**:When positioning the appliance, ensure the supply cord is not trapped or damaged.
- Do not step on the power cable.
- Ensure that the power cable is not trapped by the freezer. Do not step on the power cable.
- Do not cover air vent openings.
- Use a separate earthed socket for the power supply which is easy accessible. The appliance must be earthed.

1 - Safety

⚠ WARNING!

- **WARNING:** Do not damage the refrigerant circuit.

Daily use

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances, but not allowed to clean and install the refrigerating appliances.
- Keep away children under 3 years of age from the appliance unless they are constantly supervised.
- Cleaning and user maintenance shall not be made by children without supervision.
- The appliance must be positioned so that the plug is accessible.
- If coal gas or other inflammable gas is leaking into vicinity of the appliance, turn off the valve of the leaking gas, open the doors and windows and do not unplug the power cable of the freezer or any other appliance.
- Notice that the appliance is set for operation at the specific ambient range between 16 and 38°C. The appliance may not work properly if it is left for a long period at a temperature above or below the indicated range.
- Do not place unstable articals (heavy objects, containers filled with water) on top of the freezer,to avoid personal injury caused by falling or electric shock caused by contact with water.
- Do not store or use infammable, explosive or corrosive materials in the appliance or in the vicinity.
- Do not lift the appliance by its handles.
- Never place the appliance horizontally on the ground.
- Before any operation, frst unplug the appliance from the mains.
- Do not tilt the appliance more than 45 ° to prevent damage of the cooling system.
- Unplug the appliance in the event of a power interruption or before cleaning. Allow at least 7 minutes before restarting the appliance, as frequent starting may damage the compressor.
- Check the condition of food if a warming in the freezer has taken place.

1 - Safety

WARNING!

- Do not pull on the door shelves. The door may be pulled slant, the bottle rack, may be pulled away, or the appliance may topple.
- Open and close the door only with the handles. The gap between the door and the cabinet is very narrow. Do not put your hands in these areas to avoid pinching your fngers. Open or close the appliance doors only when there are no children standing within the range of door movement.
- Never store bottled beer or beverages in the freezer, as these will burst during freezing.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not store medicines, bacteria or chemical agents in the appliance This appliance is a household appliance. It is not recommended to store materials that require strict temperatures.
- Never store liquids in bottles or cans (besides high percentage spirits) especially carbonated beverages in the freezer as these will burst during freezing.
- Do not set unnecessarily low temperature in the freezer compartment. Minus temperatures may occur at high settings. Attention: Bottles can burst.
- Do not touch frozen goods with wet hands (wear gloves). Especially do not eat ice lollies immediately after removal from the freezer compartment. There is the risk to freeze or the formation of frost blister. FIRST aid: keep immediately under running cold water. Do not pull away!
- Do not touch the inside surface of the freezer storage compartment when in operation, especially with wet hands, as your hands may freeze onto the surface.
- **WARNING**: Do not use electrical devices inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- **WARNING**: The lamps can only be replaced by manufacturer, together with a part of the appliance.
- **WARNING**:If you are unsure of the refrigerant type check the rating plate on the back of the unit. It is hazardous for anyone other than an Authorized Service Person to service this appliance. In Queensland – the authorized Service Person MUST hold a Gas Work Authorization for hydrocarbon refrigerants, to carry out Servicing or repairs which involve the removal of covers.

WARNING!

Maintenance / cleaning

- Make sure children are supervised if they carry out cleaning and maintenance.
- Disconnect the appliance from the electrical supply before undertaking any routine maintenance. Allow at least 7 minutes before restarting the appliance, as frequent starting may damage the compressor.
- Hold the plug, not the cable, when unplugging the appliance.
- Do not clean the appliance with hard brushes, wire brushes, detergent powder, petrol, amyl acetate, acetone and similar organic solutions, acid or alkaline solutions. Please clean with special freezer detergent to avoid damage.
- Do not scrape off frost and ice with a sharp objects. Do not use sprays, electric heaters like heater, hair dryer, steam cleaners or other sources of heat in order to avoid damage to the plastic parts.
- **WARNING:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Do not try to repair, disassemble or modify the appliance by yourself. In case of repair please contact our customer service.
- Eliminate the dust on the back of the unit at least once in the year to avoid hazard by fire, as well as increased energy consumption.
- Do not spray or flush the appliance during cleaning.
- Do not use water spray or steam to clean the appliance.
- Do not clean the cold glass shelves or glass door with hot water. Sudden temperature change may cause the glass to break.
- Disconnect the appliance from the power supply before cleaning.
- In case of heating check the condition of frozen goods.
- Before maintenance, deactivate the appliance and disconnect the mains plug from the mains socket.
- Electrical equipment should be serviced only by qualifed electrical experts, because improper repairs can cause considerable consequential damages.

1 - Safety

Refrigerant gas information

WARNING!

The appliance contains the flammable refrigerant ISOBUTANE (R600a). Make sure the refrigerant circuit is not damaged during transportation or installation. Leaking refrigerant may cause eye injuries or ignite. If a damage has occurred, keep away open fire sources, thoroughly ventilate the room, do not plug or unplug the power cords of the appliance or any other appliance. Inform the customer service.

In case of eyes get into contact with the refrigerant, rinse it immediately under running water and call immediately the eye specialist.

WARNING: The refrigeration system is under high pressure. Do not tamper with it. Since the flammable refrigerants are used, please, install, handle and service the appliance strictly according to the instruction and contact the professional agent or our after-sales service to dispose of the appliance.

WARNING!

- Taking care to avoid causing a fire by igniting flammable material.
- WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged.
- WARNING: Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- For flammable refrigerants is used in the freezer, please be careful when installing, handling, serving and recycling the appliance.
- Please contact to the service agent to dispose the appliance because the flammable blowing gas was used.

Intended use

This appliance is intended to be used in household and similar applications such as

- staff kitchen areas in shops, offices and other working environments;
- farm houses and by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments;
- catering and similar non-retail applications.

► If the appliance is not used for an extended period of time,and you will not use only the fridge off function for the freezer;
- Take out the food.
- Unplug the power cord.
- Clean the appliance as described above.
- Keep the doors open to prevent the creation of bad odours inside.

► To ensure the safe preservation of foodstuffs, please comply with this instruction for use.

► The details on the most appropriate part in the compartment of the appliance where specific types of food shall be stored, considering the distribution of temperature that can be present in the different compartments of the appliance are in the other part of the manual.

► To avoid contamination of food, please respect the following instructions:
- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- Clean regularly surfaces that can come in contact with food and accessible drainage systems.
- Clean water tanks if they have not been used for 48 h; flush the water system connected to a water supply if water has not been drawn for 5 days.
- Store raw meat and fish in suitable containers in the freezer, so that it is not in contact with or drip onto other food.
- Two-star frozen-food compartments are suitable for storing pre-frozen food, storing or making ice cream and making ice cubes.

- One-, two- and three-star compartments are not suitable for the freezing of fresh food.
- If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.

Disposal

The  symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the appliacable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Since the flammable insulation blowing gases are used, please contact the professional agent or our after-sale service to dispose of the appliance.

WARNING!

Risk of injury of suffocation!

Refrigerants and gases must be disposed of professionally. Ensure that the tubing of the refrigerant circuit is not damaged before being properly disposed of. Disconnect the appliance from the mains supply. Cut off the mains cable and dispose of it. Remove the trays and drawers as well as the door catch and seals to prevent children and pets to get closed in the appliance.

2-Intended use

2.1 Intended Use

"This appliance is intended to be used in household and similar applications such as
– staff kitchen areas in shops, offices and other working environments;
– farm houses and by clients in hotels, motels and other residential type environments;
– bed and breakfast type environments;
– catering and similar non-retail applications.

This appliance is intended for freezing food. It has been designed exclusively for use in dry-interior house-holds. It is not intended for commercial or industrial use. On demand this appliance can be used as fresh food compartment.

Changes or modifications to the device are not allowed. Unintended use may cause hazards and loss of warranty claims.

2.2 Accessories

Check the accessories and literature in accordance with this list:


2.2



Warranty card




User manual



Upper right hinge for door reversibility

Upper right hinge cover




Axe covers

3-Product description

Notice: Differences

Due to technical changes and different models, some of the illustrations in this manual may differ from your model.


Picture of appliance (Fig. 3)



1 Control panel
2 LED light
3 Multi-air flow
4 Glass shelves
5 Drawers
6 Adjustable feet
7 Removable door racks
8 Door handle

4-Control panel

Control panel (Fig. 4)



Key description

A Fridge temperature adjustment key: press to select between 2, 4 and 6

B Freezer and fridge convertible function: Press the 'Freezer and fridge convertible' key(B) for 3 seconds to achieve freezer and fridge convertible function

C Freezer temperature adjustment key: press to select the temperature between - 16, - 18, - 20, - 24/ press and hold 3 seconds to enter or exit super freezer function

D Display lock and unlock key: Press and hold 3 seconds to enter or exit the lock mode

Control panel description

a 6 ℃ : the freezer is currently at 6 ℃ fridge

b 4 ℃ : the freezer is currently at 4 ℃ fridge

c 2 ℃ : the refrigerator is currently at 2 ℃ fridge

d - 16 ℃ : the freezer is currently at - 16 ℃ freezer

e - 18 ℃ : the freezer is currently at - 18 ℃ freezer

f - 20 ℃ : the freezer is currently at - 20 ℃ freezer

g - 24 ℃ : the freezer is currently at - 24 ℃ freezer

h Lock mode: the freezer is currently locked

5.1 Before first Use

- Remove all packaging materials, keep them out of children reach and dispose them in an environmentally friendly manner.
- Clean the inside and outside of the appliance with water and a mild detergent before putting any food in it.
- After the appliance has been levelled and cleaned, wait for at least 6 hours before connecting it to the power supply. See Section INSTALLATION.
- Precool the compartment for 2 hours at high settings before loading with food. To do so, please set the temperature to -20 °C or -24 °C.

5.2 Switching the appliance on /off

The appliance is in operation as soon as it is connected to the power supply.

- The freezer temperature is automatically set to -18 °C. This is the recommended setting and the ideal temperature for frozen goods. If desired, you can change the temperatures manually. Please see ADJUSTING THE TEMPERATURE.

Indicators (a-g) will flash once consequtively. If the door is closed, the display switches off after 30 seconds. The panel lock might be active.

Notice: Presettings

- The appliance is preset to the recommended temperature of -18 °C. Under normal ambient condition you don´t need to set a temperature.
- When the appliance is switched on after being disconnected from the main power supply, it may take up to 12 hours for the correct temperature to be reached.

Empty the appliance before switching off. To switch off the appliance, pull the power cord out off the power socket.

5.3 Standby-mode of display

When the door is closed the display screen turns off automatically 30 seconds after without operation. The display locks automatically. It lights up automatically when touching any button or opening the door.

5.4 Display lock and unlock

Automatic locking

The display panel can automatically enter the lock mode. The display panel is automatically locked after 30 seconds without operation.

Manual lock

When the display panel is unlocked, press the 'Lock' key(D) for 3 seconds. After a 'beep', the 'Lock' (D) indicator lights up, then the display panel enters the lock mode. When the display panel is locked, press the 'Lock'(D) for 3 seconds. After a 'beep', 'Lock'(D) indicator is off. Display panel is unlocked.

Notice: Display lock

When display is locked, functions such as temperature setting or super freeze are disabled. When above operation is attempted, The lock indicator will blink for 3 times, to remind that the display is locked.

5.5 Freezer and fridge convertible function (B)

When the display is unlocked, press the 'Freezer and fridge convertible' key(B) for 3 seconds to achieve freezer and fridge convertible function.

The freezer temperature is very different from fridge function mode, which is suitable for different food storage. If there is any mode change about the freezer and fridge, please change the food stored in the freezer to avoid damage to the stored food because of the change of function mode.

5.6 Temperature setting

Freezer temperature adjustment (C)

When the display is unlocked, press the 'Freezer and fridge convertible' key(B) for 3 seconds to enter freezer mode. After entering the freezer mode, the temperature is at - 18℃ by default. Pressing the 'Freezer Temp' key(C) then the user can select different freezer temperatures at - 18℃ / - 20℃ / - 24℃ / - 16℃ / - 18℃ cyclically.

Fridge temperature adjustment (A)

When the display is unlocked, enter the fridge function by pressing the 'Freezer and fridge convertible' key(B). After entering the fridge function, the temperature is at 4℃ by default. Pressing the 'Fridge Temp' key(A) then the user can select different fridge temperatures at 4℃ / 2℃ / 6℃ / 4℃ cyclically.

5.7 Super freeze mode

The super freeze mode is designed to preserve the nutritional value of frozen food better, which can freeze the food thoroughly in a shorter time. Please activating the super freeze mode 24 hours before putting lots of food inside the freezer. The frozen effect is better when the temperature reaches a lower temperature.

When the display is unlocked, press the 'Freezer and fridge convertible' key(B) to enter freezer mode. Then press the 'Freezer Temp' key(C) for 3 seconds, indicators (d-g) will be lighted all, indicating that the freezer works in super freeze mode. Repeat steps above can deactivate super freeze mode manually. If does not deactivated the super freezer function manually, it will be deactivated automatically after 50 hours.

Notice: Super freeze

In super freeze mode, temperature could not be adjusted. If you do so, super freeze indicator will blink for 3 times to remind that the freezer is in super freeze mode.

5.9 Eco mode (-16°C) (C)

When display is unlocked, by touching ('Freezer Temp' key) (C) the appliance is set into Eco mode. In this mode the energy consumption is lower, while appropriate freezing performance is still guaranteed. To exit the Eco mode select other temperature.

5.10 Power-of memory

This freezer has power-off memory, settings before power-off will be memorized. When power is back on, freezer will return to settings before power-off and continue to function. The lock is not memorized, after power back on, display is unlocked.

5.11 Door open alarm

When freezer is kept open for more than 1 minute, beeper will make 3 beeps with interval of 0.5 second. The beeps will be repeated every 30 seconds if door is kept open. The beeps will stop until door is closed or after 7 mins of door opening. The beeper stops beeping and freezer light goes off.

5.12 High temperature alarm

This freezer is equipped with high temperature alarm. In freeze mode or super freeze mode, if current temperature setting indicator blinks with beeps, touch any button, the beep will stop, but current temperature setting indicator keeps blinking, that means temperature in the freezer is too high. Please check if freezer door is tightly closed or if large amount of warm food is put inside the freezer. After a period, current temperature indicator will stop blinking. If it does not stop blinking for a long period, and beeps that are manually cancelled come back, please contact aftersales service.

5.13 Error indication


This freezer is equipped with error indication. When an error is encountered, display will blink every 1/4 second different codes for different errors. In this situation, the freezer could still freeze but user should contact aftersales service as soon as possible for optimal control of the freezer.

6-Energy saving tips

Energy saving tips

- Make sure the appliance is properly ventilated (see INSTALLATION).
- Do not install the appliance in direct sunlight or in the near of heat sources (e.g. stoves, heaters).
- Avoid unnecessarily low temperature in the appliance. The energy consumption increases the lower the temperature in the appliance is set.
- Allow warm food to cool down before placing it in the appliance.
- Open the appliance door as little and as briefly as possible.
- Make sure the door always closes correctly and unimpaired by food position. Keep door seals clean.
- Defreeze frozen food in a fridge.
- Clean the rear of the appliance regularly. Dust increases energy consumption.

7-Equipment




7.1

7.1 Removable door racks

The door rack can be removed for cleaning:

Place hands on each side of the rack, lift it upwards (1) and pull it out (2) (Fig. 7.3).

In order to insert the door rack, the above steps are carried out in reverse order.



7.2


7.2 Glass shelves

1. To take out a shelf, remove it first by uplifting its hind edge (1) and pulling it out (2) (Fig. 7.2).
2. To reinstall it, put it on the lugs on both sides and push it to the most rearward position until the rear of the shelf is fixed inside the slots in the sides

8-Care and Cleaning

8.1 General

Clean the appliance when only little or no food is stored.


8.1

- ► Always keep the door gasket clean.
- ► Clean the inside and housing of the appliance with a sponge damped in warm water and neutral detergent.

1. Please scrub the interior and exterior of the refrigerator, including door sealing, door rack, glass shelves, boxes ans so on,with a sofe towel or sponge dipped in warm water (you may add neutral detergent into the warm water).
2. If there is liquid spilled, remove all the contaminated parts, directly rinse with the flow water, dry and place it back into the fridge.
3. If there is spilled cream (such as the cream, melting ice cream), please remove all the contaminated parts, put into the warm water with about 40 °C for some time, then rinse with the flow water, dry and place it back into the fridge.
4. In case some small part or component gets stucked inside of the fridge (between shelves or drawers), use small soft brush to release it. If you could not reach the part, please contact Haier service.

8.2 Non-use for a longer period

If the appliance is not used for an extended period of time:

- ► Take out the food.
- ► Unplug the power cord.
- ► Clean the appliance as described above.
- ► Keep the door and freezer drawers open to prevent the creation of bad odours inside.

Remove the door of the appliance (open the door and hold it before removing the screws) to avoid children entering into the appliance and getting locked in.

Notice: Switch off

To ensure the service life of the appliance, only turn it off only if strictly necessary.

8.3 Moving the appliance

1. Remove all food and unplug the appliance.
2. Secure shelves and other moveable parts in the freezer with adhesive tape.
3. Close the door and secure it with tape.
4. Do not tilt the freezer more than 45° to avoid damaging the refrigerating system.
5. Wrap the feet of the freezer to avoid scratching the floor. Never move the freezer forcefully.

9-Troubleshooting

Many occuring problems could be solved by yourself without specific expertise. In case of a problem please check all shown possibilities and follow below instructions before you contact an after sales service. See CUSTOMER SERVICE.

The acoustic alarm can be switched of by pressing any button.

9.1 Troubleshooting

Problem	Possible Cause	Possible Solution
The compressor does not work.	• Mains plug is not connected in the mains socket.	• Connect the mains plug.
The appliance runs frequently or for a too long period of time.	• The indoor or outdoor temperature is too high. • The appliance has been off power for a period of time. • The door of the appliance is not tightly closed. • The door has been opened too frequently or for too long. • The temperature setting is too low. • The door gasket is dirty, worn, cracked or mis-matched. • The required air circulation is not guaranteed. • The interior is covered in ice.	• In this case, it is normal for the appliance to run longer. • Normally, it takes 8 to 12 hours for the appliance to cool down completely. • Close the door and ensure the appliance is located on a level ground and there is no food or container jarring the door. • Do not open the door too frequently. • Set the temperature higher until a satisfactory temperature is obtained. It takes 24 hours for the temperature to become stable. • Clean the door gasket or replace them by the customer service. • Ensure adequate ventilation. • Defrost the appliance.
The appliance makes abnormal sounds.	• The appliance is not located on level ground. • The appliance touches an object close to it. • The appliance stands on a wooden floor or near wooden walls.	• Level the appliance. • Remove objects around the appliance. • Wood amplifies the sound. Set the appliance somewhere else.
The appliance makes a clicking sound	• This is normal. It is caused by the refrigeration unit switching on or off.	• -
A slight sound is to be heard similar to that of flowing water.	• This is normal.	• -

9 - Troubleshooting

Problem	Possible Cause	Possible Solution
The appliance makes a motor sound	• The refrigeration unit has just turned itself on. This is normal	• -
It is not cold enough inside the appliance.	• The temperature is set too high. • Goods that are too warm have been stored. • Too much food has been stored at a time. • The goods are too close to each other. • The door is not tightly closed. • The door has been opened too frequently or for too long.	• Reset the temperature. • Always cool down goods before storing them. • Always store small quantities of food. • Leave a gap between several foods allowing air flowing. • Close the door. • Do not open the door too frequently.
It is too cold inside the appliance.	• The temperature is set too low. • The Fast-freezing function is activated or has been running too long.	• Reset the temperature. • Switch off the Fast-freezing function.
Moisture accumulates on the surface of the appliance.	• The climate is too warm and too damp.	• This is normal in damp climate and will change when the humidity decreases. Wipe dry with a cloth.
Strong ice and frost in the freezer compartment.	• The goods were not adequately packaged . • The door is not tightly closed. • The door has been opened too frequently or for too long. • The door gasket is dirty, worn, cracked or mis-matched. • Something on the inside prevents the door from closing properly.	• Always pack the goods well. • Close the door. • Do not open the door too frequently. • Clean the door gasket or replace them by the customer service. • Reposition the shelves, door racks, or internal containers to allow the door to close.
The cooling system does not work.	• Mains plug is not connected to the mains socket. • The power supply is not intact.	• Connect the mains plug. • Check the electrical supply to the room. Call the local electricity company!
The sides of the cabinet and door strip get warm.	• This is normal.	• -
You hear an alarm signal.	• The door is open • The temperature inside product is too high	• Close the door or silence the alarm manually.

Problem	Possible Cause	Possible Solution
The door is diffucult to open.	• Once the appliance runs, it has an internal vacuum.	• Open the door seal gently to let air enter the appliacne.
The door can't be closed properly. It always leaves a gap.	• Because of the appliances's low temperature, the door seal can easily get hard and deformed.	• Use a hair dryer or put a hot towel on the spot where the gasket is deformed. • When the gasket is soft once again, close the door and compress it tightly.

9.2 Power Interruption

In the event of a power cut, food should remain safely cold for about 18 hours. Follow these tips during a prolonged power interruption, especially in summer:

- ► Open the door as few times as possible.
- ► Do not put additional food into the freezer during a power interruption.
- ► If prior notice of a power interruption is given and the interruption duration is longer than 15 hours, make some ice and put it in a container in the top of the freezer compartment.
- ► As temperature in the freezer will rise during a power interruption or other failure, the storage period and edible quality of food will be reduced. Any food that defrosts should be either consumed, or cooked and refrozen (where suitable) soon afterwards in order to prevent health risks.

Notice: Memory function during power interruption

After restoration of power the appliance continues with the settings that were set before the power failure.


10.1 Unpacking

- Take the appliance out of the packaging.
- Remove all packaging materials.

10.2 Environmental conditions

The room temperature should always be between 18 °C and 43 °C, since it can influence the temperature inside the appliance and its energy consumption. Do not install the appliance near other heat-emitting appliances (ovens, refrigerators) without isolation.

10.3




10.3 Space requirements

Required space to open the door (Fig. 10.3):

Width in mm		Depth in mm			Distance to wall in mm
W1	W2	D1	D2	D3	D4
595	955	592	1105	1215	100


10.4



10.4 Ventilaton cross-section

To achieve sufficient ventilation of the appliance for safety reasons, the information of the required ventilation cross sections must be observed (Fig. 10.4).

10.5




10.5 Aligning the appliance

The appliance should be placed on a flat and solid surface. If the appliance is placed on a pedestal, strong and fire-resistant materials must be used. Never use the foam packing material as a pedestal.

1. Tilt the appliance slightly backwards (Fig. 10.5).
2. Set the feet to the desired level.
3. The stability can be checked by alternately bumping on the diagonals. The slight swaying should be the same in both directions. Otherwise the frame can warp; possible leaking door seals are the result. A low tendency to the rear eases the closing of the door.


10.6 Using adjustable feet



If the freezer is unstable, the feet can be adjusted: Rotate the adjustable feet according to the direction of arrow (Fig. 10.6) to turn them up or down:

- Turning the feet clockwise raises the appliance.
- Turning the feet counterclockwise lowers it.

10.7 Waiting time



To the maintenance-free lubrication oil is located in the capsule of the compressor. This oil can get through the closed pipe system during slanting transport. Before connecting the appliance to the power supply you have to wait 6 hours (Fig. 10.7) so that the oil runs back into the capsule.


10.8 Electrical connection

Before each connection check if:

- power supply, socket and fusing are appropriate to the rating plate.
- the power socket is earthed and no multi-plug or extension.
- the power plug and socket are strictly according.

Connect the plug to a properly installed household socket.

10.9 LED Lamp parameters and replacement




LED Lamp parameter: DC 12V, 1.5W

The is LED lamp, which has low energy consumption and long service life. If there is any abnormity, please do not disassemble by yourself. Please contact the after-sales staff for door-to-door service.

10.9 Door Reversibility


Before connecting the appliance to the power supply you should check, whether the door swing must changed from left (as delivered) to right, if this is required by the installation location and the usability.



Assembly steps (Fig. 10.9):


1. Provide necessary tool.
2. Unplug the appliance.
3. Remove hinge hole cover and hinge cover.
4. Unplug the connection cable.
5. Removes screws and hinge
6. Remove cover on door. Remove axe cover on door
7. Open and remove the door.
8. Turn the door upside down, remove 2 screws on the bottom of the door. Remove 2 screws, door stopper and axe cover on the bottom of the door
9. Take door stopper from last step and the thinner axe cover from the accessory bag, fix them with 2 screws. Fix 2 screws also on the other side of the door.
10. Tilt slightly backwards the cabinet, remove 4 screws and then the lower hinge.
11. Remove screw and axe cover. Remove hinge axe and fix it into the hole next to it.
12. Take the thicker axe cover from the accessory bag. Fix it with screw from last step.
13. Fix the hinge to the opposite position of the cabinet with 4 screws.
14. On opposit side of the door, pull out left side connection cable and put it through the axe cover from step 5, mount axe cover. Mount the hole cover on the right side.

10 - Installation



15. Mount the door.
16. Fix upper right upper hinge with 3 screws.
17. Connect the cable connectors:
18. Fix hinge hole cover and upper left hinge cover.
19. Finished.

10.10 Handel Reversibility



Assembly steps (Fig. 10.10):

1. Use a flat-headed screwdriver to prise off the handle upper cover. Remove the two screws and then remove the handle
2. Use a flat-headed screwdriver to pry off the screw plug on the right of the door body. Move the screw plug to the lefts side and plug the screw hole. Fix the handle on the left side and have it covered

11-Technical Data

Trade mark	Haier
Model No.	HVF325DW
Category of the model	Freezer/Refrigerator
Energy Star	Freezer:3.5 star/Fefrigerator:5.0 star
Product group	7/1
Storage volume Cooling /Freezing (L) */***	285
Frostfree system	yes
Climate class	T
Voltage / Frequency	220-240V ~/ 50Hz
Rated Current (A)	1.5
Refrigerant	R600a 44g
Dimensions (H/W/D in cm)	171/59.5/67.5
Protection Class	I

HVF325DW

Haier

0060533303